



PRODUCT-DETAILS

1724-885K

Cover frame 4gang black matt - future linear



General Information	
Extended Product Type	1724-885K
Product ID	2CKA001754A4422
EAN	4011395128336
Catalog Description	Cover frame 4gang black matt - future linear
Long Description	With small corner radii for trunking systems.
Installation	
Instructions and Manuals	No document needed
Mounting Type	Flush Mounted
Type of Fastening	Clamp
Mounting Orientation	Horizontal Vertical
Environmental	
Degree of Protection	IP20

Technical		
Data Sheet, Technical Information	No document needed	
Number of Gangs		4

Design		
Design Range	future linear Platform 63	
Design Range Variant	future linear future linear - matt	
Surface Finishing	Lacquered Matt	
Material	Thermoplastic	
Label Space Provided	No	
RAL Number	Similar to RAL 9005	
Color	black matt	

Dimensions		
Product Net Width	80 mm	
Product Net Height	293 mm	
Product Net Depth / Length	11 mm	
Product Net Weight	62.5 g	

Ordering		
E-Number (Norway)	1415874	
E-Number (Sweden)	1815056	

Material Compliance		
RoHS Information	2CKA200000E2769	
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019	
REACH Declaration	2CKA309999E9999	
REACH Information	False - does not contain substances > 0.1 mass percentage	
REACH Date	20240705	
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363	

Certificates and Declarations		
Declaration of Conformity - CE	No declaration needed	

Classifications		
ETIM 9	EC000007 - Cover frame for domestic switching devices	
eClass	V11.0 : 27144001	
WEEE Category	Product Not in WEEE Scope	

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001799A0924	Mounting Box 2 gang black matt - future linear	1702-885	1	piece
2CKA001799A0956	Mounting Box 3 gang black matt - future linear	1703-885	1	piece
2CKA001731A1980	Cover Busch-Infolicht® black matt - Platform 63	1716-885	1	piece
2CKA001731A1981	Rocker open for red pull button calotte for Push switch, Pull cord black matt - Platform 63	1720-885	1	piece
2CKA001710A3892	Cover plate with legend Level switch Turn button black matt - Platform 63	1740 DR/03-885	1	piece
2CKA001710A3893	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button black matt - Platform 63	1740 DRL-885-503	1	piece
2CKA001710A3894	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button black matt - Platform 63	1740-885	1	piece
2CKA001710A3895	Cover plate Blind cap with Mounting plate black matt - Platform 63	1742-885	1	piece
2CKA001724A4371	Cover plate SAT 4 gang black matt - Platform 63	1743/10-04-885	1	piece
2CKA001724A4380	Cover plate SAT 4 gang black matt - Platform 63	1743-04-885	1	piece
2CKA001724A4298	Cover plate SAT 3 gang black matt - Platform 63	1743-885	1	piece
2CKA001710A3896	Cover plate telephone connector boxes (VDo) black matt - Platform 63	1745-885	1	piece
2CKA001710A3897	Cover plate Telecommunication inserts 50 x 50 mm black matt - Platform 63	1746/10-885	1	piece
2CKA001710A3898	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm black matt - Platform 63	1746-885	1	piece
2CKA001710A4099	Intermediate Ring for cover plates Busch-Balance® SI black matt - Platform 63	1747 BSI-885	1	piece
2CKA001710A3900	Cover plate Cable outlet with Mounting plate black matt - Platform 63	1749-885	1	piece
2CKA001723A0259	Cover plate Loudspeaker 2 gang black matt - Platform 63	1751-885	1	piece
2CKA001710A3902	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key black matt - Platform 63	1755 SL/PZ-885-101	1	piece
2CKA001724A4299	Cover plate with labelling field For data connection housing black matt - Platform 63	1758-885	1	piece
2CKA001731A4005	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker black matt - Platform 63	1764 NLI/KI-885	1	piece
2CKA001731A1982	Rocker with labelling field for Switch/push button, Single rocker black matt - Platform 63	1764 NLI-885	1	piece
2CKA001710A3903	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang black matt - Platform 63	1766-885	1	piece
2CKA001753A0261	Cover plate with legend 1 ... 15 Min for Time switch, Turn button black matt - Platform 63	1770-885-103	1	piece
2CKA001753A0304	Cover plate with legend 10 ... 120 Min for Time switch, Turn button black matt - Platform 63	1771-885-103	1	piece
2CKA001751A3105	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker black matt - Platform 63	1785 JA/02-885	1	piece
2CKA001751A3036	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker black matt - Platform 63	1785 JA-885	1	piece
2CKA001751A3037	Rocker with legend DND, MUR for Switch/push button, Two-part rocker black matt - Platform 63	1785/11-885	1	piece
2CKA001751A3038	Rocker for Switch/push button, Two-part rocker black matt - Platform 63	1785-885	1	piece
2CKA001751A3104	Rocker with legend Symbol "arrows" black matt - Platform 63	1786 JA/02-885	1	piece
2CKA001751A3040	Rocker with legend DND for Switch/push button, Single rocker black matt - Platform 63	1786/11-885	1	piece
2CKA001751A3094	Accessories for Switch/push button, Single rocker black matt - Platform 63	1786-885-500	1	piece
2CKA001751A3042	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1788-885	1	piece

2CKA001751A3043	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 H-885	1	piece
2CKA001751A3044	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 KI-885	1	piece
2CKA001751A3045	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 LI-885	1	piece
2CKA001751A3154	Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 N-885	1	piece
2CKA001751A3164	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 ST-885	1	piece
2CKA001751A3046	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 TR-885	1	piece
2CKA001751A3047	Rocker with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1789-885	1	piece
2CKA001710A3905	Cover plate with legend Card, Symbol "arrows" Hotel card black matt - Platform 63	1792-885	1	piece
2CKA001710A3906	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1794 TA-885	1	piece
2CKA001710A3907	Cover plate Various symbols for Thermostat Turn button black matt - Platform 63	1794-885	1	piece
2CKA001710A4052	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - Platform 63	1795 HKEA-885	1	piece
2CKA001710A3908	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - Platform 63	1795 TA-885	1	piece
2CKA001710A3909	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - Platform 63	1795-885	1	piece
2CKA001753A0314	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord black matt - Platform 63	1796-885	1	piece
2CKA001710A3910	Cover plate with labelling field Modular Jack 2 gang black matt - Platform 63	1800-885	1	piece
2CKA001710A3911	Cover plate with labelling field UAE/IAE (ISDN) 2 gang black matt - Platform 63	1803-02-885	1	piece
2CKA001710A3912	Cover plate with labelling field UAE/IAE (ISDN) 1 gang black matt - Platform 63	1803-885	1	piece
2CKA002013A5410	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUAB-885	1	piece
2CKA002011A6211	Socket Outlets black matt - Platform 63	20 EUC-885-500	1	piece
2CKA002013A5421	Busch-Service-Socket SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUCBDR-885	1	piece
2CKA002013A5330	SCHUKO® socket insert Safety Shutter withControl light; LED /Green black matt - Platform 63	20 EUCBL-885	1	piece
2CKA002013A5331	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White black matt - Platform 63	20 EUCBLI-885	1	piece
2CKA002013A5332	SCHUKO® Socket insert with legend EDV Safety Shutter black matt - Platform 63	20 EUCKS/DV-885	1	piece
2CKA002013A5333	SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUCKS-885	1	piece
2CKA002013A5434	SCHUKO® Socket insert with labelling field Safety Shutter black matt - Platform 63	20 EUCNB-885	1	piece
2CKA002013A5444	SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUICRB-885	1	piece
2CKA002018A1495	SCHUKO® socket insert with Hinged Lid black matt - Platform 63	20 EUK-885	1	piece
2CKA002018A1523	SCHUKO® socket insert Safety Shutter with Hinged Lid black matt - Platform 63	20 EUKB-885	1	piece
2CKA002018A1531	SCHUKO® socket insert Safety Shutter with Hinged Lid black matt - Platform 63	20 EUKBR-885	1	piece

2CKA002018A1542	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid black matt - 20 EUKNB-885 Platform 63	1	piece
2CKA002018A1553	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid black matt - Platform 63	20 EUKNBL-885	1 piece
2CKA002018A1567	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking black matt - Platform 63	20 EUKNBSL-885	1 piece
2CKA002018A1568	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking black matt - Platform 63	20 EUKNBSL-885-101	1 piece
2CKA002011A3884	SCHUKO® Socket insert with labelling field black matt - Platform 63	20 EUN-885	1 piece
2CKA001751A3173	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO black matt - Platform 63	2029 UC-885	1 piece
2CKA002495A0092	Equipotential socket insert Equipotential compensation black matt - Platform 63	2095 UC-885	1 piece
2CKA002013A5480	SCHUKO® socket insert Safety Shutter black matt - Platform 63	23 EUCB-885	1 piece
2CKA002013A5454	SCHUKO® socket insert Safety Shutter black matt - Platform 63	2300 EUCB-885	1 piece
2CKA002113A5340	Socket Outlets Safety Shutter black matt - Platform 63	2300 UCRKS-885-503	1 piece
2CKA002011A3885	Busch-Protector® SCHUKO® socket insert with Neon lamp / Red black matt - Platform 63	2310 EUGL/VA-885-11	1 piece
2CKA002130A0295	Socket Outlets black matt - Platform 63	2332 UJBS-885	1 piece
2CKA002013A5364	Flush Mounted Inserts	2398 CKS-885	1 piece
2CKA001751A3183	Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - Platform 63	2520 KI-885	1 piece
2CKA001751A3193	Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - Platform 63	2520 LI-885	1 piece
2CKA001751A3202	Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - Platform 63	2520 TR-885	1 piece
2CKA001724A4301	Cover plate Pilot devices 1 gang black matt - Platform 63	2533-885	1 piece
2CKA001710A3913	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button black matt - Platform 63	2542 DR/01-885	1 piece
2CKA001710A3914	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button black matt - Platform 63	2542 DR/02-885	1 piece
2CKA001724A4405	Cover plate XLR 1 gang black matt - Platform 63	2553-885	1 piece
2CKA001753A0397	Cover plate Modular Jack 2 gang black matt - Platform 63	2561-02-885	1 piece
2CKA001753A0406	Cover plate Modular Jack 1 gang black matt - Platform 63	2561-885	1 piece
2CKA003116A0671	FI-Schukomat SCHUKO® socket insert Safety Shutter black matt - Platform 63	3120 EUCB-885	1 piece
2CKA003117A0013	Buschmat RCD - Insert RCD 30 mA black matt - Platform 63	3151 UC-885	1 piece
2CKA006115A0488	6108/61-885-500 Coverplate f. CE	6108/61-885-500	1 piece
2CKA006155A0065	6109/03-885-500 Coverplate f. RTC	6109/03-885-500	1 piece
2CKA006132A0381	Horizontal 0 ... 180 ° Presence Detection black matt	6122/10-885-500	1 piece
2CKA006115A0215	6125/01-885-500 Control element 1g w. BAU	6125/01-885-500	1 piece
2CKA006115A0227	6125/02-885-500 Control element 1/2gang	6125/02-885-500	1 piece
2CKA006116A0205	6126/01-885-500 Control element 2g w. BAU	6126/01-885-500	1 piece
2CKA006116A0217	6126/02-885-500 Control element 2/4gang	6126/02-885-500	1 piece
2CKA006117A0231	6127/01-885-500 Control element 4g w. BAU	6127/01-885-500	1 piece

2CKA006117A0243	6127/02-885-500 Control element 4/8gang	6127/02-885-500	1	piece
2CKA006134A0339	6128/28-885-500 RTC Control element 2/4g	6128/28-885-500	1	piece
2CKA006135A0166	6129/01-885-500 Control element 3/6g w. IR	6129/01-885-500	1	piece
2CKA006430A0386	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker black matt - Platform 63	6430-885-102	1	piece
2CKA006430A0389	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate black matt - Platform 63	6435-885	1	piece
2CKA006470A0011	Cover plate for Proximity switch One-part button black matt - Platform 63	6476-885	1	piece
2CKA006400A0063	Cover plate PowerDock 1 gang black matt - Platform 63	6477-885	1	piece
2CKA006599A2966	Cover plate for Dimmer Turn button with Neon lamp black matt - Platform 63	6540-885-102	1	piece
2CKA006599A2967	Cover plate for Cooling Central cover plate black matt - Platform 63	6541-885	1	piece
2CKA006599A2968	Control Element for Switch/dimmer Single push button black matt - Platform 63	6543-885-101	1	piece
2CKA006599A2969	Control Element for Dimmer Two-part button with Neon lamp black matt - Platform 63	6545-885	1	piece
2CKA006730A0141	Rocker for Smart switch Two-part rocker black matt - Platform 63	6736 FoH-885	1	piece
2CKA008200A0126	Cover plate Loudspeaker black matt - Platform 63	8253-885	1	piece
2CKA006220A0634	CP-FCC-885 C-plate Fan Coil	CP-FCC-885	1	piece
2CKA006220A0631	CP-RTC-885 C-plate RT sensor unit	CP-RTC-885	1	piece
2CKA006220A0632	MD-F-1.0.1-885 Movement detector	MD-F-1.0.1-885	1	piece
2CKA006220A0633	MSA-F-1.1.1-885 Mov. detector/actuator 1g	MSA-F-1.1.1-885	1	piece
2CKA006200A0098	MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	piece
2CKA006220A0618	Rocker black matt - Platform 63	SR-1-885	1	piece
2CKA006220A0623	Rocker black matt - Platform 63	SR-2-885	1	piece
2CKA006220A0620	Rocker black matt - Platform 63	SRB-1-885	1	piece
2CKA006220A0625	Rocker Symbol "arrows" black matt - Platform 63	SRB-2-885	1	piece
2CKA006220A0622	Rocker Symbol "dimming" black matt - Platform 63	SRD-1-885	1	piece
2CKA006220A0627	Rocker Symbol "dimming" black matt - Platform 63	SRD-2-L-885	1	piece
2CKA006220A0628	Rocker Symbol "dimming" black matt - Platform 63	SRD-2-R-885	1	piece
2CKA006220A0619	Rocker Symbol "light" black matt - Platform 63	SRL-1-885	1	piece
2CKA006220A0624	Rocker Symbol "light" black matt - Platform 63	SRL-2-L-885	1	piece
2CKA006220A0629	Rocker Symbol "light" black matt - Platform 63	SRL-2-R-885	1	piece
2CKA006220A0621	Rocker Symbol "scene" black matt - Platform 63	SRS-1-885	1	piece
2CKA006220A0626	Rocker Symbol "scene" black matt - Platform 63	SRS-2-L-885	1	piece
2CKA006220A0630	Rocker Symbol "scene" black matt - Platform 63	SRS-2-R-885	1	piece
2CKA001582A0346	Cover plate with labelling field Busch-Infoline® 1 gang studio white - Platform 63	1571 CN-84	1	piece
2CKA001582A0348	Cover plate with labelling field Busch-Infoline® 1 gang Clear studio white - Platform 63	1572 CN-84	1	piece
2CKA001582A0350	Cover plate with labelling field Busch-Infoline® studio white - Platform 63	1573 CN-84	1	piece
2CKA001582A0353	Cover plate with labelling field Busch-Infoline® studio white - Platform 63	1575 CN-84	1	piece
2CKA001582A0355	Cover plate with labelling field Busch-Infoline® studio white - Platform 63	1576 CN-84	1	piece
2CKA001731A1976	Cover Busch-Infolicht® grey metallic - Platform 63	1716-803	1	piece
2CKA001731A1921	Cover Busch-Infolicht® anthracite - Platform 63	1716-81	1	piece
2CKA001731A1922	Cover Busch-Infolicht® ivory white - Platform 63	1716-82	1	piece
2CKA001731A1950	Cover Busch-Infolicht® aluminium silver - Platform 63	1716-83	1	piece

2CKA001731A1923	Cover Busch-Infolicht® studio white - Platform 63	1716-84	1	piece
2CKA001731A1955	Cover Busch-Infolicht® stainless steel - Pure Stainless Steel	1716-866	1	piece
2CKA001731A1978	Cover Busch-Infolicht® studio white matt - Platform 63	1716-884	1	piece
2CKA001731A1914	Rocker open for red pull button calotte for Push switch, Pull cord anthracite - Platform 63	1720-81	1	piece
2CKA001731A1915	Rocker open for red pull button calotte for Push switch, Pull cord ivory white - Platform 63	1720-82	1	piece
2CKA001731A1949	Rocker open for red pull button calotte for Push switch, Pull cord aluminium silver - Platform 63	1720-83	1	piece
2CKA001731A1916	Rocker open for red pull button calotte for Push switch, Pull cord studio white - Platform 63	1720-84	1	piece
2CKA001731A1954	Rocker open for red pull button calotte for Push switch, Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001731A1979	Rocker open for red pull button calotte for Push switch, Pull cord studio white matt - Platform 63	1720-884	1	piece
2CKA001710A4119	Cover plate with legend Level switch Turn button grey metallic - Platform 63	1740 DR/03-803	1	piece
2CKA001710A4120	Cover plate with legend Level switch Turn button anthracite - Platform 63	1740 DR/03-81	1	piece
2CKA001710A3807	Cover plate with legend Level switch Turn button ivory white - Platform 63	1740 DR/03-82	1	piece
2CKA001710A3811	Cover plate with legend Level switch Turn button aluminium silver - Platform 63	1740 DR/03-83	1	piece
2CKA001710A3808	Cover plate with legend Level switch Turn button studio white - Platform 63	1740 DR/03-84	1	piece
2CKA001710A3812	Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	piece
2CKA001710A3870	Cover plate with legend Level switch Turn button studio white matt - Platform 63	1740 DR/03-884	1	piece
2CKA001710A4121	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button grey metallic - Platform 63	1740 DRL-803-503	1	piece
2CKA001710A4122	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button anthracite - Platform 63	1740 DRL-81-503	1	piece
2CKA001710A3511	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory white - Platform 63	1740 DRL-82-503	1	piece
2CKA001710A4123	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button aluminium silver - Platform 63	1740 DRL-83-503	1	piece
2CKA001710A3512	Cover plate Symbol "2-1-3" for Level switch, Turn button studio white - Platform 63	1740 DRL-84-503	1	piece
2CKA001710A3771	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	piece
2CKA001710A3871	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white matt - Platform 63	1740 DRL-884-503	1	piece
2CKA001710A3840	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button grey metallic - Platform 63	1740-803	1	piece
2CKA001710A3623	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button anthracite - Platform 63	1740-81	1	piece
2CKA001710A3154	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button ivory white - Platform 63	1740-82	1	piece
2CKA001710A3661	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button aluminium silver - Platform 63	1740-83	1	piece
2CKA001710A3172	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white - Platform 63	1740-84	1	piece
2CKA001710A3748	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button stainless steel - Pure Stainless Steel	1740-866	1	piece
2CKA001710A3872	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white matt - Platform 63	1740-884	1	piece

2CKA001710A3843	Cover plate Blind cap 1 gang 0 gang with Mounting plate grey metallic - Platform 63	1742-803	1	piece
2CKA001710A3612	Cover plate Blind cap with Mounting plate anthracite - Platform 63	1742-81	1	piece
2CKA001710A3143	Cover plate Blind cap with Mounting plate ivory white - Platform 63	1742-82	1	piece
2CKA001710A3664	Cover plate Blind cap with Mounting plate aluminium silver - Platform 63	1742-83	1	piece
2CKA001710A3161	Cover plate Blind cap with Mounting plate studio white - Platform 63	1742-84	1	piece
2CKA001710A3991	Cable Outlet / Blank Plate / Adapter Ring Blind cap with Mounting plate studio white - Platform 63	1742-84-500	1	piece
2CKA001710A3751	Cover plate Blind cap with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	piece
2CKA001710A3873	Cover plate Blind cap with Mounting plate studio white matt - Platform 63	1742-884	1	piece
2CKA001724A4364	Cover plate SAT 4 gang grey metallic - Platform 63	1743/10-04-803	1	piece
2CKA001724A4365	Cover plate SAT 4 gang anthracite - Platform 63	1743/10-04-81	1	piece
2CKA001724A4366	Cover plate SAT 4 gang ivory white - Platform 63	1743/10-04-82	1	piece
2CKA001724A4367	Cover plate SAT 4 gang aluminium silver - Platform 63	1743/10-04-83	1	piece
2CKA001724A4368	Cover plate SAT 4 gang studio white - Platform 63	1743/10-04-84	1	piece
2CKA001724A4369	Cover plate SAT 4 gang stainless steel - Pure Stainless Steel	1743/10-04-866	1	piece
2CKA001724A4370	Cover plate TV / Radio / 2x SAT 4 gang studio white matt - Platform 63	1743/10-04-884	1	piece
2CKA001724A4373	Cover plate TV / Radio / 2x SAT 4 gang grey metallic - Platform 63	1743-04-803	1	piece
2CKA001724A4374	Cover plate SAT 4 gang anthracite - Platform 63	1743-04-81	1	piece
2CKA001724A4375	Cover plate TV / Radio / 2x SAT 4 gang ivory white - Platform 63	1743-04-82	1	piece
2CKA001724A4376	Cover plate SAT 4 gang aluminium silver - Platform 63	1743-04-83	1	piece
2CKA001724A4377	Cover plate TV / Radio / 2x SAT 4 gang studio white - Platform 63	1743-04-84	1	piece
2CKA001724A4378	Cover plate SAT 4 gang stainless steel - Pure Stainless Steel	1743-04-866	1	piece
2CKA001724A4379	Cover plate TV / Radio / 2x SAT 4 gang studio white matt - Platform 63	1743-04-884	1	piece
2CKA001724A4291	Cover plate SAT 3 gang grey metallic - Platform 63	1743-803	1	piece
2CKA001724A4252	Cover plate SAT 3 gang anthracite - Platform 63	1743-81	1	piece
2CKA001724A2758	Cover plate SAT 3 gang ivory white - Platform 63	1743-82	1	piece
2CKA001724A4262	Cover plate SAT 3 gang aluminium silver - Platform 63	1743-83	1	piece
2CKA001724A4332	Data / Telecommunication / Antenna SAT 3 gang studio white - Platform 63	1743-84-500	1	piece
2CKA001724A4271	Cover plate SAT 3 gang stainless steel - Pure Stainless Steel	1743-866	1	piece
2CKA001724A4293	Cover plate SAT 3 gang studio white matt - Platform 63	1743-884	1	piece
2CKA001710A3855	Cover plate telephone connector boxes (VDo) grey metallic - Platform 63	1745-803	1	piece
2CKA001710A3624	Cover plate telephone connector boxes (VDo) anthracite - Platform 63	1745-81	1	piece
2CKA001710A3155	Cover plate telephone connector boxes (VDo) ivory white - Platform 63	1745-82	1	piece
2CKA001710A3675	Cover plate telephone connector boxes (VDo) aluminium silver - Platform 63	1745-83	1	piece
2CKA001710A3173	Cover plate Busch-Infoline® telephone connector boxes (VDo) Central cover plate studio white - Platform 63	1745-84	1	piece
2CKA001710A3766	Cover plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel	1745-866	1	piece
2CKA001710A3874	Cover plate telephone connector boxes (VDo) studio white matt - Platform 63	1745-884	1	piece

2CKA001710A3857	Cover plate Telecommunication inserts 50 x 50 mm grey metallic - Platform 63	1746/10-803	1	piece
2CKA001710A3628	Cover plate Telecommunication inserts 50 x 50 mm anthracite - Platform 63	1746/10-81	1	piece
2CKA001710A3521	Cover plate Telecommunication inserts 50 x 50 mm ivory white - Platform 63	1746/10-82	1	piece
2CKA001710A3677	Cover plate Telecommunication inserts 50 x 50 mm aluminium silver - Platform 63	1746/10-83	1	piece
2CKA001710A3993	Data / Telecommunication / Antenna Telecommunication inserts 0 gang studio white - Platform 63	1746/10-84-500	1	piece
2CKA001710A3768	Cover plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746/10-866	1	piece
2CKA001710A3875	Cover plate Telecommunication inserts 50 x 50 mm studio white matt - Platform 63	1746/10-884	1	piece
2CKA001710A3858	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm grey metallic - Platform 63	1746-803	1	piece
2CKA001710A3618	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm anthracite - Platform 63	1746-81	1	piece
2CKA001710A3149	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm ivory white - Platform 63	1746-82	1	piece
2CKA001710A3678	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm aluminium silver - Platform 63	1746-83	1	piece
2CKA001710A3167	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm studio white - Platform 63	1746-84	1	piece
2CKA001710A3769	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746-866	1	piece
2CKA001710A3876	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm studio white matt - Platform 63	1746-884	1	piece
2CKA001710A3862	Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - Platform 63	1747 SI-82	1	piece
2CKA001710A3863	Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI studio white - Platform 63	1747 SI-84	1	piece
2CKA001710A3860	Intermediate Ring ivory white - Platform 63	1747-82	1	piece
2CKA001710A3861	Intermediate Ring studio white - Platform 63	1747-84	1	piece
2CKA001710A3844	Cover plate Cable outlet with Mounting plate grey metallic - Platform 63	1749-803	1	piece
2CKA001710A3614	Cover plate Cable outlet with Mounting plate anthracite - Platform 63	1749-81	1	piece
2CKA001710A3145	Cover plate Cable outlet with Mounting plate ivory white - Platform 63	1749-82	1	piece
2CKA001710A3665	Cover plate Cable outlet with Mounting plate aluminium silver - Platform 63	1749-83	1	piece
2CKA001710A3163	Cover plate Cable outlet studio white - Platform 63	1749-84	1	piece
2CKA001710A3752	Cover plate Cable outlet with Mounting plate stainless steel - Pure Stainless Steel	1749-866	1	piece
2CKA001710A3878	Cover plate Cable outlet with Mounting plate studio white matt - Platform 63	1749-884	1	piece
2CKA001710A3679	Cover plate BNC/TNC 2 gang aluminium silver - Platform 63	1750-83	1	piece
2CKA001723A0257	Cover plate Loudspeaker 2 gang grey metallic - Platform 63	1751-803	1	piece
2CKA001723A0253	Cover plate Loudspeaker 2 gang anthracite - Platform 63	1751-81	1	piece
2CKA001723A0239	Cover plate Loudspeaker 2 gang ivory white - Platform 63	1751-82	1	piece
2CKA001723A0254	Cover plate Loudspeaker 2 gang aluminium silver - Platform 63	1751-83	1	piece
2CKA001723A0240	Cover plate Loudspeaker 2 gang studio white - Platform 63	1751-84	1	piece
2CKA001723A0255	Cover plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel	1751-866	1	piece
2CKA001723A0260	Cover plate Loudspeaker 2 gang studio white matt - Platform 63	1751-884	1	piece
2CKA001710A3841	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key grey metallic - Platform 63	1755 SL/PZ-803-101	1	piece

2CKA001710A3626	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key anthracite - Platform 63	1755 SL/PZ-81-101	1	piece
2CKA001710A3157	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key ivory white - Platform 63	1755 SL/PZ-82-101	1	piece
2CKA001710A3662	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key aluminium silver - Platform 63	1755 SL/PZ-83-101	1	piece
2CKA001710A3175	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white - Platform 63	1755 SL/PZ-84-101	1	piece
2CKA001710A3749	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	piece
2CKA001710A3925	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white matt - Platform 63	1755 SL/PZ-884-101	1	piece
2CKA001724A4292	Cover plate with labelling field For data connection housing grey metallic - Platform 63	1758-803	1	piece
2CKA001724A4253	Cover plate with labelling field For data connection housing anthracite - Platform 63	1758-81	1	piece
2CKA001724A2759	Cover plate with labelling field For data connection housing ivory white - Platform 63	1758-82	1	piece
2CKA001724A4263	Cover plate with labelling field For data connection housing aluminium silver - Platform 63	1758-83	1	piece
2CKA001724A2761	Cover plate with labelling field For data connection housing studio white - Platform 63	1758-84	1	piece
2CKA001724A4272	Cover plate with labelling field For data connection housing stainless steel - Pure Stainless Steel	1758-866	1	piece
2CKA001724A4307	Cover plate with labelling field For data connection housing studio white matt - Platform 63	1758-884	1	piece
2CKA001731A3997	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker grey metallic - Platform 63	1764 NLI/KI-803	1	piece
2CKA001731A3998	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker anthracite - Platform 63	1764 NLI/KI-81	1	piece
2CKA001731A3999	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker ivory white - Platform 63	1764 NLI/KI-82	1	piece
2CKA001731A4000	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - Platform 63	1764 NLI/KI-83	1	piece
2CKA001731A4003	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	piece
2CKA001731A4004	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Platform 63	1764 NLI/KI-884	1	piece
2CKA001731A4011	Rocker with labelling field for Switch/push button, Single rocker red - Platform 63	1764 NLI-12-82-101	1	piece
2CKA001731A4007	Rocker with labelling field for Switch/push button, Single rocker green - Platform 63	1764 NLI-13-82	1	piece
2CKA001731A1975	Rocker with labelling field for Switch/push button, Single rocker grey metallic - Platform 63	1764 NLI-803	1	piece
2CKA001731A1552	Rocker with labelling field for Switch/push button, Single rocker anthracite - Platform 63	1764 NLI-81	1	piece
2CKA001731A1876	Rocker with labelling field for Switch/push button, Single rocker ivory white - Platform 63	1764 NLI-82	1	piece
2CKA001731A1948	Rocker with labelling field for Switch/push button, Single rocker aluminium silver - Platform 63	1764 NLI-83	1	piece
2CKA001731A1877	Rocker with labelling field for Switch/push button, Single rocker studio white - Platform 63	1764 NLI-84	1	piece
2CKA001731A1953	Rocker with labelling field for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001731A1985	Rocker with labelling field for Switch/push button, Single rocker studio white matt - Platform 63	1764 NLI-884	1	piece
2CKA001710A3854	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang grey metallic - Platform 63	1766-803	1	piece

2CKA001710A3613	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang anthracite - Platform 63	1766-81	1	piece
2CKA001710A3144	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang ivory white - Platform 63	1766-82	1	piece
2CKA001710A3659	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang aluminium silver - Platform 63	1766-83	1	piece
2CKA001710A3992	Data / Telecommunication / Antenna TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 0 gang studio white - Platform 63	1766-84-500	1	piece
2CKA001710A3765	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang stainless steel - Pure Stainless Steel	1766-866	1	piece
2CKA001710A3926	Cover plate TAE; UAE / TAE; USB / VGA / HDMI / loudspeaker 1 gang studio white matt - Platform 63	1766-884	1	piece
2CKA001753A0254	Cover plate 1 ... 15 Min for Time switch, Turn button grey metallic - Platform 63	1770-803-103	1	piece
2CKA001753A0255	Cover plate with legend 1 ... 15 Min for Time switch, Turn button anthracite - Platform 63	1770-81-103	1	piece
2CKA001753A0256	Cover plate with legend 1 ... 15 Min for Time switch, Turn button ivory white - Platform 63	1770-82-103	1	piece
2CKA001753A0257	Cover plate with legend 1 ... 15 Min for Time switch, Turn button aluminium silver - Platform 63	1770-83-103	1	piece
2CKA001753A0258	Cover plate with legend 1 ... 15 Min for Time switch, Turn button studio white - Platform 63	1770-84-103	1	piece
2CKA001753A0259	Cover plate with legend 1 ... 15 Min for Time switch, Turn button stainless steel - Pure Stainless Steel	1770-866-103	1	piece
2CKA001753A0260	Cover plate with legend 1 ... 15 Min for Time switch, Turn button studio white matt - Platform 63	1770-884-103	1	piece
2CKA001753A0264	Cover plate 10 ... 120 Min for Time switch, Turn button grey metallic - Platform 63	1771-803-103	1	piece
2CKA001753A0265	Cover plate with legend 10 ... 120 Min for Time switch, Turn button anthracite - Platform 63	1771-81-103	1	piece
2CKA001753A0266	Cover plate with legend 10 ... 120 Min for Time switch, Turn button ivory white - Platform 63	1771-82-103	1	piece
2CKA001753A0267	Cover plate with legend 10 ... 120 Min for Time switch, Turn button aluminium silver - Platform 63	1771-83-103	1	piece
2CKA001753A0301	Cover plate with legend 10 ... 120 Min for Time switch, Turn button studio white - Platform 63	1771-84-103	1	piece
2CKA001753A0302	Cover plate with legend 10 ... 120 Min for Time switch, Turn button stainless steel - Pure Stainless Steel	1771-866-103	1	piece
2CKA001753A0303	Cover plate with legend 10 ... 120 Min for Time switch, Turn button studio white matt - Platform 63	1771-884-103	1	piece
2CKA001751A2977	Multimedia Devices anthracite	1785 ENO-81	1	piece
2CKA001751A2978	Multimedia Devices ivory white	1785 ENO-82	1	piece
2CKA001751A2979	Multimedia Devices aluminium silver	1785 ENO-83	1	piece
2CKA001751A2980	Multimedia Devices studio white	1785 ENO-84	1	piece
2CKA001751A3101	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker ivory white - Platform 63	1785 JA/02-82	1	piece
2CKA001751A3097	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker aluminium silver - Platform 63	1785 JA/02-83	1	piece
2CKA001751A3099	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker studio white - Platform 63	1785 JA/02-84	1	piece
2CKA001751A3103	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker studio white matt - Platform 63	1785 JA/02- 884	1	piece
2CKA001751A3020	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker grey metallic - Platform 63	1785 JA-803	1	piece
2CKA001751A2934	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker anthracite - Platform 63	1785 JA-81	1	piece
2CKA001751A2748	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker ivory white - Platform 63	1785 JA-82	1	piece

2CKA001751A2944	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker aluminium silver - Platform 63	1785 JA-83	1	piece
2CKA001751A3088	Accessories Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker studio white - Platform 63	1785 JA-84-500	1	piece
2CKA001751A2964	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker stainless steel - Pure Stainless Steel	1785 JA-866	1	piece
2CKA001751A3022	Rocker with legend Symbol "arrows" 2 gang(s), for Venetian blind, Two-part rocker studio white matt - Platform 63	1785 JA-884	1	piece
2CKA001751A3126	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785 K-83-500	1	piece
2CKA001751A3128	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker studio white - Platform 63	1785 K-84-500	1	piece
2CKA001751A3204	Rocker with legend DND, MUR for Switch/push button, Single rocker grey metallic - Platform 63	1785/11-803	1	piece
2CKA001751A3205	Rocker with legend DND, MUR for Switch/push button, Two-part rocker anthracite - Platform 63	1785/11-81	1	piece
2CKA001751A2991	Rocker with legend DND, MUR for Switch/push button, Two-part rocker ivory white - Platform 63	1785/11-82	1	piece
2CKA001751A2995	Rocker with legend DND, MUR for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785/11-83	1	piece
2CKA001751A2992	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white - Platform 63	1785/11-84	1	piece
2CKA001751A2996	Rocker with legend DND, MUR for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	piece
2CKA001751A3023	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white matt - Platform 63	1785/11-884	1	piece
2CKA001751A3018	Rocker for Switch/push button, Two-part rocker grey metallic - Platform 63	1785-803	1	piece
2CKA001751A2930	Rocker for Switch/push button, Two-part rocker anthracite - Platform 63	1785-81	1	piece
2CKA001751A2744	Rocker for Switch/push button, Two-part rocker ivory white - Platform 63	1785-82	1	piece
2CKA001751A2942	Rocker for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785-83	1	piece
2CKA001751A3092	Accessories for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785-83-500	1	piece
2CKA001751A3076	Accessories for Switch/push button, Two-part rocker studio white - Platform 63	1785-84-500	1	piece
2CKA001751A3087	Accessories for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3024	Rocker for Switch/push button, Two-part rocker studio white matt - Platform 63	1785-884	1	piece
2CKA001751A2965	Multimedia Devices anthracite	1786 ENO-81	1	piece
2CKA001751A2966	Multimedia Devices ivory white	1786 ENO-82	1	piece
2CKA001751A2967	Multimedia Devices aluminium silver	1786 ENO-83	1	piece
2CKA001751A2968	Multimedia Devices studio white	1786 ENO-84	1	piece
2CKA001751A3100	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker ivory white - Platform 63	1786 JA/02-82	1	piece
2CKA001751A3096	Rocker with legend Symbol "arrows" for Switch/push button, aluminium silver - Platform 63	1786 JA/02-83	1	piece
2CKA001751A3098	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white - Platform 63	1786 JA/02-84	1	piece
2CKA001751A3102	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white matt - Platform 63	1786 JA/02-884	1	piece
2CKA001751A3207	Rocker with legend DND for Switch/push button, Single rocker anthracite - Platform 63	1786/11-81	1	piece
2CKA001751A2997	Rocker with legend DND for Switch/push button, Single rocker ivory white - Platform 63	1786/11-82	1	piece

2CKA001751A3001	Rocker with legend DND for Switch/push button, Single rocker aluminium silver - Platform 63	1786/11-83	1	piece
2CKA001751A2998	Rocker with legend DND for Switch/push button, Single rocker studio white - Platform 63	1786/11-84	1	piece
2CKA001751A3002	Rocker with legend DND for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	piece
2CKA001751A3026	Rocker with legend DND for Switch/push button, Single rocker studio white matt - Platform 63	1786/11-884	1	piece
2CKA001751A3145	Rocker for Switch/push button, Single rocker red - Platform 63	1786-12-82	1	piece
2CKA001751A3093	Mechanical Controls for Switch/push button, Single rocker grey metallic - Platform 63	1786-803-500	1	piece
2CKA001751A3079	Mechanical Controls for Switch/push button, Single rocker anthracite - Platform 63	1786-81-500	1	piece
2CKA001751A3083	Accessories for Switch/push button, Single rocker ivory white - Platform 63	1786-82-500	1	piece
2CKA001751A3075	Accessories for Switch/push button, Single rocker aluminium silver - Platform 63	1786-83-500	1	piece
2CKA001751A3074	Accessories for Switch/push button, Single rocker studio white - Platform 63	1786-84-500	1	piece
2CKA001751A3077	Mechanical Controls for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A3089	Accessories for Switch/push button, Single rocker studio white matt - Platform 63	1786-884-500	1	piece
2CKA001751A3017	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1788-803	1	piece
2CKA001751A2927	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1788-81	1	piece
2CKA001751A2742	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1788-82	1	piece
2CKA001751A2954	Rocker with legend Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1788-83	1	piece
2CKA001751A2750	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1788-84	1	piece
2CKA001751A2961	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1788-866	1	piece
2CKA001751A3028	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1788-884	1	piece
2CKA001751A3019	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 H-803	1	piece
2CKA001751A2929	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 H-81	1	piece
2CKA001751A2743	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 H-82	1	piece
2CKA001751A2955	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 H-83	1	piece
2CKA001751A2751	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 H-84	1	piece
2CKA001751A2963	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 H-866	1	piece
2CKA001751A3029	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 H-884	1	piece

2CKA001751A3015	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 KI-803	1	piece
2CKA001751A2932	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 KI-81	1	piece
2CKA001751A2746	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 KI-82	1	piece
2CKA001751A2952	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 KI-83	1	piece
2CKA001751A2754	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 KI-84	1	piece
2CKA001751A2959	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	piece
2CKA001751A3030	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 KI-884	1	piece
2CKA001751A3014	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 LI-803	1	piece
2CKA001751A2931	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 LI-81	1	piece
2CKA001751A2745	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 LI-82	1	piece
2CKA001751A2951	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 LI-83	1	piece
2CKA001751A3084	Mechanical Controls Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 LI-84-500	1	piece
2CKA001751A2958	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A3031	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 LI-884	1	piece
2CKA001751A3146	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 N-803	1	piece
2CKA001751A3147	Rocker with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 N-81	1	piece
2CKA001751A3148	Rocker with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 N-82	1	piece
2CKA001751A3149	Rocker with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 N-83	1	piece
2CKA001751A3151	Mechanical Controls with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 N-84-500	1	piece
2CKA001751A3152	Rocker with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A3153	Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 N-884	1	piece
2CKA001751A3156	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 ST-803	1	piece
2CKA001751A3157	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 ST-81	1	piece

2CKA001751A3158	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 ST-82	1	piece
2CKA001751A3159	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 ST-83	1	piece
2CKA001751A3161	Mechanical Controls Various symbols with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 ST-84-500	1	piece
2CKA001751A3162	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	piece
2CKA001751A3163	Rocker with legend Symbol "plug" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 ST-884	1	piece
2CKA001751A3016	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 TR-803	1	piece
2CKA001751A2933	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 TR-81	1	piece
2CKA001751A2747	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 TR-82	1	piece
2CKA001751A2953	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 TR-83	1	piece
2CKA001751A2755	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 TR-84	1	piece
2CKA001751A2960	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	piece
2CKA001751A3032	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 TR-884	1	piece
2CKA001751A3013	Rocker with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789-803	1	piece
2CKA001751A2928	Rocker with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789-81	1	piece
2CKA001751A2813	Rocker with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789-82	1	piece
2CKA001751A2945	Rocker with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789-83	1	piece
2CKA001751A3091	Mechanical Controls with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789-84-500	1	piece
2CKA001751A2957	Rocker with Small Red Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001751A3033	Rocker with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789-884	1	piece
2CKA001710A4111	Cover plate studio white - Platform 63	1790-590-84	1	piece
2CKA001710A4112	Cover plate studio white - Platform 63	1790-591-84	1	piece
2CKA001710A4113	Cover plate studio white - Platform 63	1790-592-84	1	piece
2CKA001710A4114	Cover plate studio white - Platform 63	1790-593-84	1	piece
2CKA001710A4115	Cover plate studio white - Platform 63	1790-594-84	1	piece
2CKA001710A4116	Cover plate studio white - Platform 63	1790-595-84	1	piece
2CKA001710A4124	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card grey metallic - Platform 63	1792-803	1	piece
2CKA001710A3639	Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - Platform 63	1792-81	1	piece
2CKA001710A3640	Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - Platform 63	1792-82	1	piece

2CKA001710A3670	Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - Platform 63	1792-83	1	piece
2CKA001710A3757	Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel	1792-866	1	piece
2CKA001710A3928	Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - Platform 63	1792-884	1	piece
2CKA001710A3849	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1794 TA-803	1	piece
2CKA001710A3695	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1794 TA-81	1	piece
2CKA001710A3696	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1794 TA-82	1	piece
2CKA001710A3697	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1794 TA-83	1	piece
2CKA001710A3698	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1794 TA-84	1	piece
2CKA001710A3761	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	piece
2CKA001710A3883	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1794 TA-884	1	piece
2CKA001710A3847	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1794-803	1	piece
2CKA001710A3629	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1794-81	1	piece
2CKA001710A3668	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1794-83	1	piece
2CKA001710A3884	Cover plate Various symbols for Thermostat Turn button studio white matt - Platform 63	1794-884	1	piece
2CKA001710A4012	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1795 HK-803	1	piece
2CKA001710A4015	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1795 HK-82	1	piece
2CKA001710A4017	Cover plate Various symbols for Thermostat Turn button studio white - Platform 63	1795 HK-84	1	piece
2CKA001710A4018	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	piece
2CKA001710A4044	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - Platform 63	1795 HKEA- 803	1	piece
2CKA001710A4045	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - Platform 63	1795 HKEA-81	1	piece
2CKA001710A4047	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - Platform 63	1795 HKEA-82	1	piece
2CKA001710A4048	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - Platform 63	1795 HKEA-83	1	piece
2CKA001710A4049	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - Platform 63	1795 HKEA-84	1	piece
2CKA001710A4050	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 HKEA- 866	1	piece
2CKA001710A4051	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - Platform 63	1795 HKEA- 884	1	piece
2CKA001710A3850	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - Platform 63	1795 TA-803	1	piece

2CKA001710A3722	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - Platform 63	1795 TA-81	1	piece
2CKA001710A3723	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - Platform 63	1795 TA-82	1	piece
2CKA001710A3724	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - Platform 63	1795 TA-83	1	piece
2CKA001710A3725	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - Platform 63	1795 TA-84	1	piece
2CKA001710A3762	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 TA-866	1	piece
2CKA001710A3885	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - Platform 63	1795 TA-884	1	piece
2CKA001710A3848	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - Platform 63	1795-803	1	piece
2CKA001710A3630	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - Platform 63	1795-81	1	piece
2CKA001710A3568	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - Platform 63	1795-82	1	piece
2CKA001710A3669	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - Platform 63	1795-83	1	piece
2CKA001710A3569	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - Platform 63	1795-84	1	piece
2CKA001710A3756	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795-866	1	piece
2CKA001710A3886	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - Platform 63	1795-884	1	piece
2CKA001753A0307	Cover plate Pull cord grey metallic - Platform 63	1796-803	1	piece
2CKA001753A0308	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord anthracite - Platform 63	1796-81	1	piece
2CKA001753A0309	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord ivory white - Platform 63	1796-82	1	piece
2CKA001753A0310	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord aluminium silver - Platform 63	1796-83	1	piece
2CKA001753A0311	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord studio white - Platform 63	1796-84	1	piece
2CKA001753A0312	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord stainless steel - Pure Stainless Steel	1796-866	1	piece
2CKA001753A0313	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord studio white matt - Platform 63	1796-884	1	piece
2CKA001710A3856	Cover plate with labelling field Modular Jack 2 gang grey metallic - Platform 63	1800-803	1	piece
2CKA001710A3627	Cover plate with labelling field Modular Jack 2 gang anthracite - Platform 63	1800-81	1	piece
2CKA001710A3158	Cover plate with labelling field Modular Jack 2 gang ivory white - Platform 63	1800-82	1	piece
2CKA001710A3676	Cover plate with labelling field Modular Jack 2 gang aluminium silver - Platform 63	1800-83	1	piece
2CKA001710A3990	Data / Telecommunication / Antenna Modular Jack 2 gang studio white - Platform 63	1800-84-500	1	piece
2CKA001710A3767	Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel	1800-866	1	piece
2CKA001710A3887	Cover plate with labelling field Modular Jack 2 gang studio white matt - Platform 63	1800-884	1	piece

2CKA001710A3853	Cover plate with labelling field UAE/IAE (ISDN) 2 gang grey metallic - Platform 63	1803-02-803	1	piece
2CKA001710A3615	Cover plate with labelling field UAE/IAE (ISDN) 2 gang anthracite - Platform 63	1803-02-81	1	piece
2CKA001710A3146	Cover plate with labelling field UAE/IAE (ISDN) 2 gang ivory white - Platform 63	1803-02-82	1	piece
2CKA001710A3610	Cover plate with labelling field UAE/IAE (ISDN) 2 gang aluminium silver - Platform 63	1803-02-83	1	piece
2CKA001710A1551	Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang studio white - Platform 63	1803-02-84-500	1	piece
2CKA001710A3764	Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel	1803-02-866	1	piece
2CKA001710A3888	Cover plate with labelling field UAE/IAE (ISDN) 2 gang studio white matt - Platform 63	1803-02-884	1	piece
2CKA001710A3852	Cover plate with labelling field UAE/IAE (ISDN) 1 gang grey metallic - Platform 63	1803-803	1	piece
2CKA001710A3616	Cover plate with labelling field UAE/IAE (ISDN) 1 gang anthracite - Platform 63	1803-81	1	piece
2CKA001710A3147	Cover plate with labelling field UAE/IAE (ISDN) 1 gang ivory white - Platform 63	1803-82	1	piece
2CKA001710A3674	Cover plate with labelling field UAE/IAE (ISDN) 1 gang aluminium silver - Platform 63	1803-83	1	piece
2CKA001710A1550	Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang studio white - Platform 63	1803-84-500	1	piece
2CKA001710A3763	Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel	1803-866	1	piece
2CKA001710A3889	Cover plate with labelling field UAE/IAE (ISDN) 1 gang studio white matt - Platform 63	1803-884	1	piece
2CKA002013A5404	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter anthracite - Platform 63	20 EUAB-81	1	piece
2CKA002013A5405	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter ivory white - Platform 63	20 EUAB-82	1	piece
2CKA002013A5406	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	20 EUAB-83	1	piece
2CKA002013A5407	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter studio white - Platform 63	20 EUAB-84	1	piece
2CKA002013A5408	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUAB-866	1	piece
2CKA002013A5409	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	20 EUAB-884	1	piece
2CKA002011A6260	SCHUKO® Socket insert with legend SV green - Platform 63	20 EUC-13-82-101	1	piece
2CKA002011A3723	SCHUKO® Socket insert with legend ZSV orange - Platform 63	20 EUC-14-82	1	piece
2CKA002011A6216	Socket Outlets grey metallic - Platform 63	20 EUC-803-500	1	piece
2CKA002011A6215	Socket Outlets anthracite - Platform 63	20 EUC-81-500	1	piece
2CKA002011A6214	Socket Outlets ivory white - Platform 63	20 EUC-82-500	1	piece
2CKA002011A6213	Socket Outlets aluminium silver - Platform 63	20 EUC-83-500	1	piece
2CKA002011A6207	Socket Outlets studio white - Platform 63	20 EUC-84-500	1	piece
2CKA002011A6212	Socket Outlets stainless steel - Pure Stainless Steel	20 EUC-866-500	1	piece
2CKA002011A6208	Socket Outlets studio white matt - Platform 63	20 EUC-884-500	1	piece
2CKA002013A5472	SCHUKO® Socket insert with legend SV Safety Shutter green - Platform 63	20 EUCB-13-82-102	1	piece
2CKA002013A5413	SCHUKO® Socket insert with legend ZSV Safety Shutter orange - Platform 63	20 EUCB-14-82-10	1	piece
2CKA002013A5414	Busch-Service-Socket SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	20 EUCBDR-803	1	piece

2CKA002013A5415	Busch-Service-Socket SCHUKO® socket insert Safety Shutter anthracite - Platform 63	20 EUCBDR-81	1	piece
2CKA002013A5416	Busch-Service-Socket SCHUKO® socket insert Safety Shutter ivory white - Platform 63	20 EUCBDR-82	1	piece
2CKA002013A5417	Busch-Service-Socket SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	20 EUCBDR-83	1	piece
2CKA002013A5418	Busch-Service-Socket SCHUKO® socket insert Safety Shutter studio white - Platform 63	20 EUCBDR-84	1	piece
2CKA002013A5419	Busch-Service-Socket SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	piece
2CKA002013A5467	SCHUKO® socket insert Safety Shutter withControl light; LED /Green green - Platform 63	20 EUCBL-13-84-101	1	piece
2CKA002013A5288	SCHUKO® socket insert Safety Shutter withControl light; LED /Green orange - Platform 63	20 EUCBL-14-84	1	piece
2CKA002013A5456	SCHUKO® socket insert Safety Shutter withControl light; LED /Green grey metallic - Platform 63	20 EUCBL-803	1	piece
2CKA002013A5457	SCHUKO® socket insert Safety Shutter withControl light; LED /Green anthracite - Platform 63	20 EUCBL-81	1	piece
2CKA002013A5284	SCHUKO® socket insert Safety Shutter withControl light; LED /Green ivory white - Platform 63	20 EUCBL-82	1	piece
2CKA002013A5285	SCHUKO® socket insert Safety Shutter withControl light; LED /Green aluminium silver - Platform 63	20 EUCBL-83	1	piece
2CKA002013A5286	SCHUKO® socket insert Safety Shutter withControl light; LED /Green studio white - Platform 63	20 EUCBL-84	1	piece
2CKA002013A5289	SCHUKO® socket insert Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel	20 EUCBL-866	1	piece
2CKA002013A5336	SCHUKO® socket insert Safety Shutter withControl light; LED /Green studio white matt - Platform 63	20 EUCBL-884	1	piece
2CKA002013A5458	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White grey metallic - Platform 63	20 EUCBLI-803	1	piece
2CKA002013A5459	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White anthracite - Platform 63	20 EUCBLI-81	1	piece
2CKA002013A5292	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White ivory white - Platform 63	20 EUCBLI-82	1	piece
2CKA002013A5293	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White aluminium silver - Platform 63	20 EUCBLI-83	1	piece
2CKA002013A5294	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White studio white - Platform 63	20 EUCBLI-84	1	piece
2CKA002013A5460	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	piece
2CKA002013A5326	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White studio white matt - Platform 63	20 EUCBLI-884	1	piece
2CKA002013A5463	SCHUKO® socket insert EDV Safety Shutter red - Platform 63	20 EUCKS/DV-12-82-101	1	piece
2CKA002013A5462	SCHUKO® Socket insert with legend EDV Safety Shutter grey metallic - Platform 63	20 EUCKS/DV-803	1	piece
2CKA002013A5266	SCHUKO® Socket insert with legend EDV Safety Shutter anthracite - Platform 63	20 EUCKS/DV-81	1	piece
2CKA002013A5267	SCHUKO® Socket insert with legend EDV Safety Shutter ivory white - Platform 63	20 EUCKS/DV-82	1	piece
2CKA002013A5273	SCHUKO® Socket insert with legend EDV Safety Shutter aluminium silver - Platform 63	20 EUCKS/DV-83	1	piece
2CKA002013A5268	SCHUKO® Socket insert with legend EDV Safety Shutter studio white - Platform 63	20 EUCKS/DV-84	1	piece

2CKA002013A5277	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter stainless steel - Pure Stainless Steel 866	1	piece
2CKA002013A5327	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter studio white matt - Platform 63 884	1	piece
2CKA002013A5464	SCHUKO® socket insert Safety Shutter red - 20 EUCKS-12- Platform 63 82-101	1	piece
2CKA002013A5470	SCHUKO® socket insert Safety Shutter green - 20 EUCKS-13- Platform 63 82-101	1	piece
2CKA002013A5324	SCHUKO® socket insert Safety Shutter orange - 20 EUCKS-14- Platform 63 82	1	piece
2CKA002013A5297	SCHUKO® socket insert Safety Shutter grey 20 EUCKS-803 metallic - Platform 63	1	piece
2CKA002013A5265	SCHUKO® socket insert Safety Shutter anthracite 20 EUCKS-81 - Platform 63	1	piece
2CKA002013A5376	Socket Outlets Safety Shutter ivory white - 20 EUCKS-82- Platform 63 500	1	piece
2CKA002013A5375	Socket Outlets Safety Shutter aluminium silver - 20 EUCKS-83- Platform 63 500	1	piece
2CKA002013A5372	Socket insert Safety Shutter studio white - 20 EUCKS-84- Platform 63 500	1	piece
2CKA002013A5374	Socket Outlets Safety Shutter stainless steel - 20 EUCKS-866 Pure Stainless Steel -500	1	piece
2CKA002013A5373	Socket insert Safety Shutter studio white matt - 20 EUCKS-884 Platform 63 -500	1	piece
2CKA002013A5423	SCHUKO® Socket insert with labelling field 20 EUCNB-12- Safety Shutter red - Platform 63 82	1	piece
2CKA002013A5424	SCHUKO® Socket insert with labelling field 20 EUCNB-13- Safety Shutter green - Platform 63 82	1	piece
2CKA002013A5425	SCHUKO® Socket insert with labelling field 20 EUCNB-14- Safety Shutter orange - Platform 63 82	1	piece
2CKA002013A5426	SCHUKO® Socket insert with labelling field 20 EUCNB-803 Safety Shutter grey metallic - Platform 63	1	piece
2CKA002013A5427	SCHUKO® Socket insert with labelling field 20 EUCNB-81 Safety Shutter anthracite - Platform 63	1	piece
2CKA002013A5428	SCHUKO® Socket insert with labelling field 20 EUCNB-82 Safety Shutter ivory white - Platform 63	1	piece
2CKA002013A5429	SCHUKO® Socket insert with labelling field 20 EUCNB-83 Safety Shutter aluminium silver - Platform 63	1	piece
2CKA002013A5432	SCHUKO® Socket insert with labelling field 20 EUCNB-866 Safety Shutter stainless steel - Pure Stainless Steel	1	piece
2CKA002013A5433	SCHUKO® Socket insert with labelling field 20 EUCNB-884 Safety Shutter studio white matt - Platform 63	1	piece
2CKA002013A5436	SCHUKO® socket insert Safety Shutter grey 20 EUCRB-803 metallic - Platform 63	1	piece
2CKA002013A5437	SCHUKO® socket insert Safety Shutter anthracite 20 EUCRB-81 - Platform 63	1	piece
2CKA002013A5438	SCHUKO® socket insert Safety Shutter ivory 20 EUCRB-82 white - Platform 63	1	piece
2CKA002013A5439	SCHUKO® socket insert Safety Shutter 20 EUCRB-83 aluminium silver - Platform 63	1	piece
2CKA002013A5441	Socket Outlets studio white - Platform 63 20 EUCRB-84- 500	1	piece
2CKA002013A5442	SCHUKO® socket insert Safety Shutter stainless 20 EUCRB-866 steel - Pure Stainless Steel	1	piece
2CKA002013A5443	SCHUKO® socket insert Safety Shutter studio 20 EUCRB-884 white matt - Platform 63	1	piece
2CKA002018A1493	SCHUKO® socket insert with Hinged Lid grey 20 EUK-803 metallic - Platform 63	1	piece
2CKA002018A1486	SCHUKO® socket insert with Hinged Lid 20 EUK-81 anthracite - Platform 63	1	piece
2CKA002018A1465	SCHUKO® socket insert with Hinged Lid ivory 20 EUK-82 white - Platform 63	1	piece
2CKA002018A1487	SCHUKO® socket insert with Hinged Lid 20 EUK-83 aluminium silver - Platform 63	1	piece
2CKA002018A1509	Socket Outlets with Hinged Lid studio white - 20 EUK-84-500 Platform 63	1	piece

2CKA002018A1490	SCHUKO® socket insert with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	piece
2CKA002018A1494	SCHUKO® socket insert with Hinged Lid studio white matt - Platform 63	20 EUK-884	1	piece
2CKA002018A1516	SCHUKO® socket insert Safety Shutter with Hinged Lid grey metallic - Platform 63	20 EUKB-803	1	piece
2CKA002018A1517	SCHUKO® socket insert Safety Shutter with Hinged Lid anthracite - Platform 63	20 EUKB-81	1	piece
2CKA002018A1518	SCHUKO® socket insert Safety Shutter with Hinged Lid ivory white - Platform 63	20 EUKB-82	1	piece
2CKA002018A1519	SCHUKO® socket insert Safety Shutter with Hinged Lid aluminium silver - Platform 63	20 EUKB-83	1	piece
2CKA002018A1520	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white - Platform 63	20 EUKB-84	1	piece
2CKA002018A1521	SCHUKO® socket insert Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	piece
2CKA002018A1522	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white matt - Platform 63	20 EUKB-884	1	piece
2CKA002018A1525	SCHUKO® socket insert Safety Shutter with Hinged Lid grey metallic - Platform 63	20 EUKBR-803	1	piece
2CKA002018A1526	SCHUKO® socket insert Safety Shutter with Hinged Lid anthracite - Platform 63	20 EUKBR-81	1	piece
2CKA002018A1527	SCHUKO® socket insert Safety Shutter with Hinged Lid ivory white - Platform 63	20 EUKBR-82	1	piece
2CKA002018A1528	SCHUKO® socket insert Safety Shutter with Hinged Lid aluminium silver - Platform 63	20 EUKBR-83	1	piece
2CKA002018A1529	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white - Platform 63	20 EUKBR-84	1	piece
2CKA002018A1530	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white matt - Platform 63	20 EUKBR-884	1	piece
2CKA002018A1533	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid red - Platform 63	20 EUKNB-12-82	1	piece
2CKA002018A1534	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid green - Platform 63	20 EUKNB-13-82	1	piece
2CKA002018A1535	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid orange - Platform 63	20 EUKNB-14-82	1	piece
2CKA002018A1536	SCHUKO® socket insert Safety Shutter with Hinged Lid grey metallic - Platform 63	20 EUKNB-803	1	piece
2CKA002018A1537	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid anthracite - Platform 63	20 EUKNB-81	1	piece
2CKA002018A1538	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid ivory white - Platform 63	20 EUKNB-82	1	piece
2CKA002018A1539	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid aluminium silver - Platform 63	20 EUKNB-83	1	piece
2CKA002018A1540	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid studio white - Platform 63	20 EUKNB-84	1	piece
2CKA002018A1541	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid studio white matt - Platform 63	20 EUKNB-884	1	piece
2CKA002018A1544	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid red - Platform 63	20 EUKNBL-12-82	1	piece
2CKA002018A1545	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid green - Platform 63	20 EUKNBL-13-82	1	piece
2CKA002018A1546	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid orange - Platform 63	20 EUKNBL-14-82	1	piece
2CKA002018A1547	SCHUKO® socket insert Safety Shutter with Hinged Lid grey metallic - Platform 63	20 EUKNBL-803	1	piece
2CKA002018A1548	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid anthracite - Platform 63	20 EUKNBL-81	1	piece

2CKA002018A1551	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid studio white - 20 EUKNBL-84 Platform 63	1	piece
2CKA002018A1552	SCHUKO® Socket insert with labelling field Safety Shutter with Control light with Hinged Lid studio white matt - Platform 63	20 EUKNBL-884	1 piece
2CKA002018A1557	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking anthracite - Platform 63	20 EUKNBSL-81	1 piece
2CKA002018A1558	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking anthracite - Platform 63	20 EUKNBSL-81-101	1 piece
2CKA002018A1559	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking ivory white - Platform 63	20 EUKNBSL-82	1 piece
2CKA002018A1560	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking ivory white - Platform 63	20 EUKNBSL-82-101	1 piece
2CKA002018A1561	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking aluminium silver - Platform 63	20 EUKNBSL-83	1 piece
2CKA002018A1562	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking aluminium silver - Platform 63	20 EUKNBSL-83-101	1 piece
2CKA002018A1563	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white - Platform 63	20 EUKNBSL-84	1 piece
2CKA002018A1564	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white - Platform 63	20 EUKNBSL-84-101	1 piece
2CKA002018A1565	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white matt - Platform 63	20 EUKNBSL-884	1 piece
2CKA002018A1566	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white matt - Platform 63	20 EUKNBSL-884-101	1 piece
2CKA002011A3876	SCHUKO® Socket insert with labelling field grey metallic - Platform 63	20 EUN-803	1 piece
2CKA002011A3802	SCHUKO® Socket insert with labelling field anthracite - Platform 63	20 EUN-81	1 piece
2CKA002011A3726	SCHUKO® Socket insert with labelling field ivory white - Platform 63	20 EUN-82	1 piece
2CKA002011A3810	SCHUKO® Socket insert with labelling field aluminium silver - Platform 63	20 EUN-83	1 piece
2CKA002011A6209	Socket Outlets studio white - Platform 63	20 EUN-84-500	1 piece
2CKA002011A3851	SCHUKO® Socket insert with labelling field stainless steel - Pure Stainless Steel	20 EUN-866	1 piece
2CKA002011A3881	SCHUKO® Socket insert with labelling field studio white matt - Platform 63	20 EUN-884	1 piece
2CKA001012A2159	Fan switch - Busch-axcent	2000/6 UJ/01	1 piece
2CKA001012A2200	Fan switch - Busch-axcent	2000/6 UJ/02	1 piece
2CKA001012A2201	Fan switch - Busch-axcent	2000/6 UJ/03	1 piece
2CKA001012A2203	Fan switch - Busch-axcent	2000/6 UJ/04	1 piece
2CKA001012A2205	Fan switch - Busch-axcent	2000/6 UJ/05	1 piece
2CKA001012A2208	Fan switch - Busch-axcent	2000/6 UJ/09	1 piece
2CKA002014A1371	Mechanical Controls	20-02 EUJP-82-503	1 piece
2CKA001751A3167	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO anthracite - Platform 63	2029 UC-81	1 piece

2CKA001751A3170	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, with LED 1NO studio white - Platform 63	2029 UC-84	1	piece
2CKA001751A3171	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO stainless steel - Pure Stainless Steel	2029 UC-866	1	piece
2CKA001510A0005	Cover Busch-iceLight Reflector Ambient / orientation lightning / White transparent - Platform 63	2068/11-84	1	piece
2CKA001510A0008	Cover Busch-iceLight Reflector Ambient / orientation lightning, Infolight transparent - Platform 63	2068/14-84	1	piece
2CKA001510A0017	Cover Busch-iceLight Ambient lightning transparent - Platform 63	2068/22-84	1	piece
2CKA001510A0015	Busch-iceLight set Busch-iceLight Reflector Night light; LED / White studio white - future linear	2069/11-84	1	piece
2CKA002495A0084	Equipotential socket insert Equipotential compensation anthracite - Platform 63	2095 UC-81	1	piece
2CKA002495A0085	Equipotential socket insert Equipotential compensation ivory white - Platform 63	2095 UC-82	1	piece
2CKA002495A0089	Equipotential socket insert Equipotential compensation aluminium silver - Platform 63	2095 UC-83	1	piece
2CKA002495A0086	Equipotential socket insert Equipotential compensation studio white - Platform 63	2095 UC-84	1	piece
2CKA002495A0090	Equipotential socket insert Equipotential compensation stainless steel - Pure Stainless Steel	2095 UC-866	1	piece
2CKA002495A0091	Equipotential socket insert Equipotential compensation studio white matt - Platform 63	2095 UC-884	1	piece
2CKA002190A0224	Socket Outlets grey metallic - Platform 63	2190 EUC-803	1	piece
2CKA002190A0216	Socket Outlets anthracite - Platform 63	2190 EUC-81	1	piece
2CKA002190A0213	Socket Outlets ivory white - Platform 63	2190 EUC-82	1	piece
2CKA002190A0214	Socket Outlets aluminium silver - Platform 63	2190 EUC-83	1	piece
2CKA002190A0215	Socket Outlets studio white - Platform 63	2190 EUC-84	1	piece
2CKA002190A0217	Socket Outlets stainless steel - Pure Stainless Steel	2190 EUC-866	1	piece
2CKA002190A0218	Socket Outlets studio white matt - Platform 63	2190 EUC-884	1	piece
2CKA002013A5474	SCHUKO® socket insert Safety Shutter anthracite - Platform 63	23 EUCB-81	1	piece
2CKA002013A5475	SCHUKO® socket insert Safety Shutter ivory white - Platform 63	23 EUCB-82	1	piece
2CKA002013A5476	SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	23 EUCB-83	1	piece
2CKA002013A5477	SCHUKO® socket insert Safety Shutter studio white - Platform 63	23 EUCB-84	1	piece
2CKA002013A5478	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	23 EUCB-866	1	piece
2CKA002013A5479	SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	23 EUCB-884	1	piece
2CKA002013A5447	SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	2300 EUCB-803	1	piece
2CKA002013A5448	SCHUKO® socket insert Safety Shutter anthracite - Platform 63	2300 EUCB-81	1	piece
2CKA002013A5449	SCHUKO® socket insert Safety Shutter ivory white - Platform 63	2300 EUCB-82	1	piece
2CKA002013A5450	SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	2300 EUCB-83	1	piece
2CKA002013A5451	SCHUKO® socket insert Safety Shutter studio white - Platform 63	2300 EUCB-84	1	piece
2CKA002013A5452	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	2300 EUCB-866	1	piece
2CKA002013A5453	SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	2300 EUCB-884	1	piece
2CKA002113A5339	Socket Outlets Safety Shutter anthracite - Platform 63	2300 UCRKS-81-503	1	piece
2CKA002113A0510	Socket Outlets Safety Shutter ivory white - Platform 63	2300 UCRKS-82-503	1	piece

2CKA002113A0511	Socket Outlets Safety Shutter studio white - Platform 63	2300 UCRKS-84-503	1	piece
2CKA002113A5337	Socket Outlets Safety Shutter studio white matt - Platform 63	2300 UCRKS-884-503	1	piece
2CKA002011A6257	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red red - Platform 63	2310 EUGL/VA-12-82-101	1	piece
2CKA002011A3830	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red anthracite - Platform 63	2310 EUGL/VA-81-11	1	piece
2CKA002011A3831	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red ivory white - Platform 63	2310 EUGL/VA-82-11	1	piece
2CKA002011A3832	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red aluminium silver - Platform 63	2310 EUGL/VA-83-11	1	piece
2CKA002011A3833	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red studio white - Platform 63	2310 EUGL/VA-84-11	1	piece
2CKA002011A3877	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red grey metallic - Platform 63	2310 EUGL/VA-803-11	1	piece
2CKA002011A3853	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red stainless steel - Pure Stainless Steel	2310 EUGL/VA-866-11	1	piece
2CKA002011A3882	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red studio white matt - Platform 63	2310 EUGL/VA-884-11	1	piece
2CKA002099A0197	Flush Mounted Inserts	2397 UCKS-82-505	1	piece
2CKA002099A0198	Flush Mounted Inserts	2397 UCKS-84-505	1	piece
2CKA002099A0253	Socket Outlets Safety Shutter grey metallic - Platform 63	2399 UCKS-803	1	piece
2CKA002099A0216	Socket Outlets Safety Shutter anthracite - Platform 63	2399 UCKS-81	1	piece
2CKA002099A0211	Socket Outlets Safety Shutter ivory white - Platform 63	2399 UCKS-82	1	piece
2CKA002099A0191	Socket Outlets Safety Shutter ivory white - Platform 63	2399 UCKS-82-505	1	piece
2CKA002099A0241	Socket Outlets Safety Shutter aluminium silver - Platform 63	2399 UCKS-83	1	piece
2CKA002099A0214	Socket insert Safety Shutter studio white - Platform 63	2399 UCKS-84	1	piece
2CKA002099A0192	Socket Outlets Safety Shutter studio white - Platform 63	2399 UCKS-84-505	1	piece
2CKA002099A0243	Socket Safety Shutter stainless steel - Pure Stainless Steel	2399 UCKS-866	1	piece
2CKA002099A0255	Socket Outlets Safety Shutter studio white matt - Platform 63	2399 UCKS-884	1	piece
2CKA001751A3175	Rocker with legend Symbol "bell" for Switch/push button, Single rocker grey metallic - Platform 63	2520 KI-803	1	piece
2CKA001751A3176	Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - Platform 63	2520 KI-81	1	piece
2CKA001751A3177	Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - Platform 63	2520 KI-82	1	piece
2CKA001751A3178	Rocker with legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 KI-83	1	piece
2CKA001751A3180	Rocker with legend Symbol "bell" for Switch/push button Single rocker studio white - Platform 63	2520 KI-84-500	1	piece
2CKA001751A3181	Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 KI-866	1	piece
2CKA001751A3182	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Platform 63	2520 KI-884	1	piece
2CKA001751A3185	Rocker for Switch/push button, Single rocker grey metallic - Platform 63	2520 LI-803	1	piece
2CKA001751A3186	Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - Platform 63	2520 LI-81	1	piece
2CKA001751A3187	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - Platform 63	2520 LI-82	1	piece

2CKA001751A3188	Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 LI-83	1	piece
2CKA001751A3191	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3192	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - Platform 63	2520 LI-884	1	piece
2CKA001751A3195	Rocker Symbol "key" for Switch/push button, Single rocker grey metallic - Platform 63	2520 TR-803	1	piece
2CKA001751A3196	Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - Platform 63	2520 TR-81	1	piece
2CKA001751A3197	Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - Platform 63	2520 TR-82	1	piece
2CKA001751A3198	Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 TR-83	1	piece
2CKA001751A3199	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - Platform 63	2520 TR-84	1	piece
2CKA001751A3200	Rocker with legend Symbol "key" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	piece
2CKA001751A3201	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - Platform 63	2520 TR-884	1	piece
2CKA001724A4407	Cover plate Pilot devices grey metallic - Platform 63	2533-803	1	piece
2CKA001724A4254	Cover plate Pilot devices 1 gang anthracite - Platform 63	2533-81	1	piece
2CKA001724A4255	Cover plate Pilot devices 1 gang ivory white - Platform 63	2533-82	1	piece
2CKA001724A4382	Cover plate Pilot devices 1 gang yellow - Platform 63	2533-82-15	1	piece
2CKA001724A4261	Cover plate Pilot devices 1 gang aluminium silver - Platform 63	2533-83	1	piece
2CKA001724A4256	Cover plate Pilot devices 1 gang studio white - Platform 63	2533-84	1	piece
2CKA001724A4270	Cover plate Pilot devices 1 gang stainless steel - Pure Stainless Steel	2533-866	1	piece
2CKA001724A4296	Cover plate Pilot devices 1 gang studio white matt - Platform 63	2533-884	1	piece
2CKA001710A4125	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button grey metallic - Platform 63	2542 DR/01-803	1	piece
2CKA001710A3644	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button anthracite - Platform 63	2542 DR/01-81	1	piece
2CKA001710A3645	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button ivory white - Platform 63	2542 DR/01-82	1	piece
2CKA001710A3671	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button aluminium silver - Platform 63	2542 DR/01-83	1	piece
2CKA001710A3646	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - Platform 63	2542 DR/01-84	1	piece
2CKA001710A3758	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/01-866	1	piece
2CKA001710A3890	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white matt - Platform 63	2542 DR/01-884	1	piece
2CKA001710A4126	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button grey metallic - Platform 63	2542 DR/02-803	1	piece
2CKA001710A3649	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button anthracite - Platform 63	2542 DR/02-81	1	piece
2CKA001710A3650	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory white - Platform 63	2542 DR/02-82	1	piece
2CKA001710A3672	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button aluminium silver - Platform 63	2542 DR/02-83	1	piece

2CKA001710A3651	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - Platform 63	2542 DR/02-84	1	piece
2CKA001710A3759	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/02-866	1	piece
2CKA001710A3891	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white matt - Platform 63	2542 DR/02-884	1	piece
2CKA001724A4385	Cover plate Call unit studio white - Platform 63	2548-020 F-84	1	piece
2CKA001724A4387	Cover plate 1 gang Red studio white - Platform 63	2548-022 A-84	1	piece
2CKA001724A4388	Cover plate Doctor 1 gang Blue studio white - Platform 63	2548-022 AR-84	1	piece
2CKA001724A4389	Cover plate Call module 1 gang Red studio white - Platform 63	2548-022 B-84	1	piece
2CKA001724A4390	Cover plate Pull-cord switch studio white - Platform 63	2548-046 A-84	1	piece
2CKA001724A4391	Cover plate Call module 1 gang Red studio white - Platform 63	2548-071 D-84	1	piece
2CKA001724A4392	Cover plate Call module 1 gang Red studio white - Platform 63	2548-071 E-84	1	piece
2CKA001724A4393	Cover plate Call / reset 2 gang Red / Green studio white - Platform 63	2548-642 B-84	1	piece
2CKA001724A4395	Cover plate Reset 1 gang Green studio white - Platform 63	2548-642 C-84	1	piece
2CKA001724A4398	Cover plate XLR grey metallic - Platform 63	2553-803	1	piece
2CKA001724A4399	Cover plate XLR 1 gang anthracite - Platform 63	2553-81	1	piece
2CKA001724A4400	Cover plate XLR 1 gang ivory white - Platform 63	2553-82	1	piece
2CKA001724A4401	Cover plate XLR 1 gang aluminium silver - Platform 63	2553-83	1	piece
2CKA001724A4402	Cover plate XLR 1 gang studio white - Platform 63	2553-84	1	piece
2CKA001724A4403	Cover plate XLR 1 gang stainless steel - Pure Stainless Steel	2553-866	1	piece
2CKA001724A4404	Cover plate XLR 1 gang studio white matt - Platform 63	2553-884	1	piece
2CKA001753A0316	Cover plate Modular Jack 2 gang grey metallic - Platform 63	2561-02-803	1	piece
2CKA001753A0317	Cover plate Modular Jack 2 gang anthracite - Platform 63	2561-02-81	1	piece
2CKA001753A0392	Cover plate Modular Jack ivory white - Platform 63	2561-02-82	1	piece
2CKA001753A0393	Cover plate Modular Jack 2 gang aluminium silver - Platform 63	2561-02-83	1	piece
2CKA001753A0394	Cover plate Modular Jack 2 gang studio white - Platform 63	2561-02-84	1	piece
2CKA001753A0395	Cover plate Modular Jack 2 gang stainless steel - Pure Stainless Steel	2561-02-866	1	piece
2CKA001753A0396	Cover plate Modular Jack 2 gang studio white matt - Platform 63	2561-02-884	1	piece
2CKA001753A0399	Cover plate Modular Jack 1 gang grey metallic - Platform 63	2561-803	1	piece
2CKA001753A0400	Cover plate Modular Jack 1 gang anthracite - Platform 63	2561-81	1	piece
2CKA001753A0401	Cover plate Modular Jack 1 gang ivory white - Platform 63	2561-82	1	piece
2CKA001753A0402	Cover plate Modular Jack 1 gang aluminium silver - Platform 63	2561-83	1	piece
2CKA001753A0403	Cover plate Modular Jack 1 gang studio white - Platform 63	2561-84	1	piece
2CKA001753A0404	Cover plate Modular Jack 1 gang stainless steel - Pure Stainless Steel	2561-866	1	piece
2CKA001753A0405	Cover plate Modular Jack 1 gang studio white matt - Platform 63	2561-884	1	piece
2CKA003116A0666	FI-Schukomat SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	3120 EUCEB-803	1	piece
2CKA003116A0667	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA anthracite - Platform 63	3120 EUCEB-81	1	piece

2CKA003116A0661	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA ivory white - Platform 63	3120 EUCB-82	1	piece
2CKA003116A0668	FI-Schukomat SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	3120 EUCB-83	1	piece
2CKA003116A0662	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA studio white - Platform 63	3120 EUCB-84	1	piece
2CKA003116A0669	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA stainless steel - Pure Stainless Steel	3120 EUCB-866	1	piece
2CKA003116A0670	FI-Schukomat SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	3120 EUCB-884	1	piece
2CKA003117A0008	Buschmat RCD - Insert RCD 30 mA grey metallic - Platform 63	3151 UC-803	1	piece
2CKA003117A0009	Buschmat RCD - Insert RCD 30 mA anthracite - Platform 63	3151 UC-81	1	piece
2CKA003117A0005	Buschmat RCD - Insert RCD 30 mA ivory white - Platform 63	3151 UC-82	1	piece
2CKA003117A0010	Buschmat RCD - Insert RCD 30 mA aluminium silver - Platform 63	3151 UC-83	1	piece
2CKA003117A0006	Buschmat RCD - Insert RCD 30 mA studio white - Platform 63	3151 UC-84	1	piece
2CKA003117A0011	Buschmat RCD - Insert RCD 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	piece
2CKA003117A0012	Buschmat RCD - Insert RCD 30 mA studio white matt - Platform 63	3151 UC-884	1	piece
2CKA006115A0489	6108/61-803-500 Coverplate f. CE	6108/61-803-500	1	piece
2CKA006115A0483	6108/61-81-500 Coverplate f. CE	6108/61-81-500	1	piece
2CKA006115A0484	6108/61-82-500 Coverplate f. CE	6108/61-82-500	1	piece
2CKA006115A0485	6108/61-83-500 Coverplate f. CE	6108/61-83-500	1	piece
2CKA006155A0121	6108/61-840-500 Coverplate f. CE	6108/61-840-500	1	piece
2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84-500	1	piece
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	piece
2CKA006115A0487	6108/61-884-500 Coverplate f. CE	6108/61-884-500	1	piece
2CKA006155A0066	6109/03-803-500 Coverplate f. RTC	6109/03-803-500	1	piece
2CKA006155A0060	6109/03-81-500 Coverplate f. RTC	6109/03-81-500	1	piece
2CKA006155A0061	6109/03-82-500 Coverplate f. RTC	6109/03-82-500	1	piece
2CKA006155A0062	6109/03-83-500 Coverplate f. RTC	6109/03-83-500	1	piece
2CKA006155A0114	6109/03-840-500 Coverplate f. RTC	6109/03-840-500	1	piece
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84-500	1	piece
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	piece
2CKA006155A0064	6109/03-884-500 Coverplate f. RTC	6109/03-884-500	1	piece
2CKA006132A0382	Horizontal 0 ... 180 ° Presence Detection grey metallic	6122/10-803-500	1	piece
2CKA006132A0376	Horizontal 0 ... 180 ° Presence Detection anthracite	6122/10-81-500	1	piece
2CKA006132A0377	Horizontal 0 ... 180 ° Presence Detection ivory white	6122/10-82-500	1	piece
2CKA006132A0378	Horizontal 0 ... 180 ° Presence Detection aluminium silver	6122/10-83-500	1	piece

2CKA006132A0407	6122/10-840-500 BW standard	6122/10-840-500	1	piece
2CKA006132A0379	Horizontal 0 ... 180 ° Presence Detection studio white	6122/10-84-500	1	piece
2CKA006132A0385	Horizontal 0 ... 180 ° Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units stainless steel	6122/10-866-500	1	piece
2CKA006132A0380	Horizontal 0 ... 180 ° Presence Detection studio white matt	6122/10-884-500	1	piece
2CKA006115A0212	6125/01-803-500 Control element 1g w. BAU	6125/01-803-500	1	piece
2CKA006115A0205	6125/01-81-500 Control element 1g w. BAU	6125/01-81-500	1	piece
2CKA006115A0206	6125/01-82-500 Control element 1g w. BAU	6125/01-82-500	1	piece
2CKA006115A0207	6125/01-83-500 Control element 1g w. BAU	6125/01-83-500	1	piece
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84-500	1	piece
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	piece
2CKA006115A0214	6125/01-884-500 Control element 1g w. BAU	6125/01-884-500	1	piece
2CKA006115A0224	6125/02-803-500 Control element 1/2gang	6125/02-803-500	1	piece
2CKA006115A0216	6125/02-81-500 Control element 1/2gang	6125/02-81-500	1	piece
2CKA006115A0217	6125/02-82-500 Control element 1/2gang	6125/02-82-500	1	piece
2CKA006115A0218	6125/02-83-500 Control element 1/2gang	6125/02-83-500	1	piece
2CKA006115A0452	6125/02-840-500 cont.-element KNX 1g	6125/02-840-500	1	piece
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84-500	1	piece
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	piece
2CKA006115A0226	6125/02-884-500 Control element 1/2gang	6125/02-884-500	1	piece
2CKA006116A0202	6126/01-803-500 Control element 2g w. BAU	6126/01-803-500	1	piece
2CKA006116A0195	6126/01-81-500 Control element 2g w. BAU	6126/01-81-500	1	piece
2CKA006116A0196	6126/01-82-500 Control element 2g w. BAU	6126/01-82-500	1	piece
2CKA006116A0197	6126/01-83-500 Control element 2g w. BAU	6126/01-83-500	1	piece
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84-500	1	piece
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	piece
2CKA006116A0204	6126/01-884-500 Control element 2g w. BAU	6126/01-884-500	1	piece
2CKA006116A0214	6126/02-803-500 Control element 2/4gang	6126/02-803-500	1	piece
2CKA006116A0206	6126/02-81-500 Control element 2/4gang	6126/02-81-500	1	piece
2CKA006116A0207	6126/02-82-500 Control element 2/4gang	6126/02-82-500	1	piece
2CKA006116A0208	6126/02-83-500 Control element 2/4gang	6126/02-83-500	1	piece
2CKA006116A0227	6126/02-840-500 cont.-element KNX 2g	6126/02-840-500	1	piece
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84-500	1	piece
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	piece

2CKA006116A0216	6126/02-884-500 Control element 2/4gang	6126/02-884-500	1	piece
2CKA006117A0228	6127/01-803-500 Control element 4g w. BAU	6127/01-803-500	1	piece
2CKA006117A0221	6127/01-81-500 Control element 4g w. BAU	6127/01-81-500	1	piece
2CKA006117A0222	6127/01-82-500 Control element 4g w. BAU	6127/01-82-500	1	piece
2CKA006117A0223	6127/01-83-500 Control element 4g w. BAU	6127/01-83-500	1	piece
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84-500	1	piece
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	piece
2CKA006117A0230	6127/01-884-500 Control element 4g w. BAU	6127/01-884-500	1	piece
2CKA006117A0240	6127/02-803-500 Control element 4/8gang	6127/02-803-500	1	piece
2CKA006117A0232	6127/02-81-500 Control element 4/8gang	6127/02-81-500	1	piece
2CKA006117A0233	6127/02-82-500 Control element 4/8gang	6127/02-82-500	1	piece
2CKA006117A0234	6127/02-83-500 Control element 4/8gang	6127/02-83-500	1	piece
2CKA006117A0252	6127/02-840-500 cont.-element KNX 4g	6127/02-840-500	1	piece
2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84-500	1	piece
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	piece
2CKA006117A0242	6127/02-884-500 Control element 4/8gang	6127/02-884-500	1	piece
2CKA006134A0336	6128/28-803-500 RTC Control element 2/4g	6128/28-803-500	1	piece
2CKA006134A0331	6128/28-81-500 RTC Control element 2/4g	6128/28-81-500	1	piece
2CKA006134A0332	6128/28-82-500 RTC Control element 2/4g	6128/28-82-500	1	piece
2CKA006134A0333	6128/28-83-500 RTC Control element 2/4g	6128/28-83-500	1	piece
2CKA006134A0342	6128/28-840-500 RTC Control element 2/4g	6128/28-840-500	1	piece
2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84-500	1	piece
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	piece
2CKA006134A0338	6128/28-884-500 RTC Control element 2/4g	6128/28-884-500	1	piece
2CKA006135A0163	6129/01-803-500 Control element 3/6g w. IR	6129/01-803-500	1	piece
2CKA006135A0156	6129/01-81-500 Control element 3/6g w. IR	6129/01-81-500	1	piece
2CKA006135A0157	6129/01-82-500 Control element 3/6g w. IR	6129/01-82-500	1	piece
2CKA006135A0158	6129/01-83-500 Control element 3/6g w. IR	6129/01-83-500	1	piece
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84-500	1	piece
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	piece
2CKA006135A0165	6129/01-884-500 Control element 3/6g w. IR	6129/01-884-500	1	piece
2CKA006430A0350	Control Element Symbol "arrows" for Venetian blind grey metallic - Platform 63	6430-803-102	1	piece
2CKA006430A0326	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker anthracite - Platform 63	6430-81-102	1	piece

2CKA006430A0327	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker ivory white - Platform 63	6430-82-102	1	piece
2CKA006430A0328	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker aluminium silver - Platform 63	6430-83-102	1	piece
2CKA006430A0400	Electronic Controls Symbol "arrows" for Venetian blind studio white - Platform 63	6430-84-102-500	1	piece
2CKA006430A0343	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker stainless steel - Pure Stainless Steel	6430-866-102	1	piece
2CKA006430A0385	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker studio white matt - Platform 63	6430-884-102	1	piece
2CKA006430A0351	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate grey metallic - Platform 63	6435-803	1	piece
2CKA006430A0303	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate anthracite - Platform 63	6435-81	1	piece
2CKA006430A0304	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate ivory white - Platform 63	6435-82	1	piece
2CKA006430A0305	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate aluminium silver - Platform 63	6435-83	1	piece
2CKA006430A0306	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate studio white - Platform 63	6435-84	1	piece
2CKA006430A0344	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate stainless steel - Pure Stainless Steel	6435-866	1	piece
2CKA006430A0388	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate studio white matt - Platform 63	6435-884	1	piece
2CKA006470A0006	Cover plate for Proximity switch One-part button grey metallic - Platform 63	6476-803	1	piece
2CKA006470A0003	Cover plate for Proximity switch One-part button ivory white - Platform 63	6476-82	1	piece
2CKA006470A0008	Cover plate for Proximity switch One-part button aluminium silver - Platform 63	6476-83	1	piece
2CKA006470A0009	Cover plate for Proximity switch One-part button stainless steel - Pure Stainless Steel	6476-866	1	piece
2CKA006470A0010	Cover plate for Proximity switch One-part button studio white matt - Platform 63	6476-884	1	piece
2CKA006400A0060	Cover plate PowerDock 1 gang grey metallic - Platform 63	6477-803	1	piece
2CKA006400A0056	Cover plate PowerDock 1 gang anthracite - Platform 63	6477-81	1	piece
2CKA006400A0057	Cover plate PowerDock 1 gang ivory white - Platform 63	6477-82	1	piece
2CKA006400A0058	Cover plate PowerDock 1 gang aluminium silver - Platform 63	6477-83	1	piece
2CKA006400A0059	Cover plate PowerDock 1 gang studio white - Platform 63	6477-84	1	piece
2CKA006400A0064	Cover plate PowerDock 1 gang stainless steel - Pure Stainless Steel	6477-866	1	piece
2CKA006400A0062	Cover plate PowerDock 1 gang studio white matt - Platform 63	6477-884	1	piece
2CKA006599A2980	Cover plate for Dimmer Turn button with Neon lamp grey metallic - Platform 63	6540-803-102	1	piece
2CKA006599A2950	Cover plate for Dimmer Turn button with Neon lamp anthracite - Platform 63	6540-81-102	1	piece
2CKA006599A2951	Cover plate for Dimmer Turn button with Neon lamp ivory white - Platform 63	6540-82-102	1	piece
2CKA006599A2952	Cover plate for Dimmer Turn button with Neon lamp aluminium silver - Platform 63	6540-83-102	1	piece
2CKA006599A3009	Electronic Controls for Dimmer Turn button studio white - Platform 63	6540-84-102-500	1	piece

2CKA006599A2959	Cover plate for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel	6540-866-102	1	piece
2CKA006599A2961	Cover plate for Dimmer Turn button with Neon lamp studio white matt - Platform 63	6540-884-102	1	piece
2CKA006599A2882	Cover plate for Cooling Central cover plate anthracite - Platform 63	6541-81	1	piece
2CKA006599A2832	Cover plate for Cooling Central cover plate ivory white - Platform 63	6541-82	1	piece
2CKA006599A2885	Cover plate for Cooling Central cover plate aluminium silver - Platform 63	6541-83	1	piece
2CKA006599A2835	Cover plate for Cooling Central cover plate studio white - Platform 63	6541-84	1	piece
2CKA006599A2924	Cover plate for Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	piece
2CKA006599A2962	Cover plate for Cooling Central cover plate studio white matt - Platform 63	6541-884	1	piece
2CKA006599A2881	Control Element for Switch/dimmer Single push button anthracite - Platform 63	6543-81-101	1	piece
2CKA006599A2831	Control Element for Switch/dimmer Single push button ivory white - Platform 63	6543-82-101	1	piece
2CKA006599A2887	Control Element for Switch/dimmer Single push button aluminium silver - Platform 63	6543-83-101	1	piece
2CKA006599A3010	Electronic Controls for Switch/dimmer Single push button studio white - Platform 63	6543-84-101-500	1	piece
2CKA006599A2926	Control Element for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006599A2963	Control Element for Switch/dimmer Single push button studio white matt - Platform 63	6543-884-101	1	piece
2CKA006599A2943	Control Element for Dimmer Two-part button with Neon lamp grey metallic - Platform 63	6545-803	1	piece
2CKA006599A2906	Control Element for Dimmer Two-part button with Neon lamp anthracite - Platform 63	6545-81	1	piece
2CKA006599A2907	Control Element for Dimmer Two-part button with Neon lamp ivory white - Platform 63	6545-82	1	piece
2CKA006599A2914	Control Element for Dimmer Two-part button with Neon lamp aluminium silver - Platform 63	6545-83	1	piece
2CKA006599A2908	Control Element for Dimmer Two-part button with Neon lamp studio white - Platform 63	6545-84	1	piece
2CKA006599A2927	Control Element for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	piece
2CKA006599A2964	Control Element for Dimmer Two-part button with Neon lamp studio white matt - Platform 63	6545-884	1	piece
2CKA006710A0011	Friends of Hue Smart Switch set 4 channel Wireless studio white - future linear	6716 UJ-84-500	1	piece
2CKA006730A0032	Wall sensor 1 channel Wireless ivory white - Platform 63	6731-82-500	1	piece
2CKA006730A0035	Wall sensor 1 channel Wireless aluminium silver - Platform 63	6731-83-500	1	piece
2CKA006730A0038	Wall sensor 1 channel Wireless studio white - Platform 63	6731-84-500	1	piece
2CKA006730A0041	WaveLine Wall sensor 1 channel Wireless stainless steel - Pure Stainless Steel	6731-866-500	1	piece
2CKA006730A0033	Wall sensor 2 channel Wireless ivory white - Platform 63	6732-82-500	1	piece
2CKA006730A0036	Wall sensor 2 channel Wireless aluminium silver - Platform 63	6732-83-500	1	piece
2CKA006730A0039	Wall sensor 2 channel Wireless studio white - Platform 63	6732-84-500	1	piece
2CKA006730A0042	Wall sensor 2 channel Wireless stainless steel - Pure Stainless Steel	6732-866-500	1	piece
2CKA006730A0034	Wall sensor 4 channel Wireless ivory white - Platform 63	6733-82-500	1	piece
2CKA006730A0037	Wall sensor 4 channel Wireless aluminium silver - Platform 63	6733-83-500	1	piece
2CKA006730A0040	Wall sensor 4 channel Wireless studio white - Platform 63	6733-84-500	1	piece
2CKA006730A0043	Wall sensor 4 channel Wireless stainless steel - Pure Stainless Steel	6733-866-500	1	piece

2CKA006730A0137	Rocker for Smart switch Two-part rocker grey metallic - Platform 63	6736 FoH-803	1	piece
2CKA006730A0133	Rocker for Smart switch Two-part rocker anthracite - Platform 63	6736 FoH-81	1	piece
2CKA006730A0134	Rocker for Smart switch Two-part rocker ivory white - Platform 63	6736 FoH-82	1	piece
2CKA006730A0135	Rocker for Smart switch Two-part rocker aluminium silver - Platform 63	6736 FoH-83	1	piece
2CKA006730A0136	Rocker for Smart switch Two-part rocker studio white - Platform 63	6736 FoH-84	1	piece
2CKA006730A0139	Rocker for Smart switch Two-part rocker stainless steel - Pure Stainless Steel	6736 FoH-866	1	piece
2CKA006730A0140	Rocker for Smart switch Two-part rocker studio white matt - Platform 63	6736 FoH-884	1	piece
2CKA006800A2830	Electronic Controls ivory white - Platform 63	6815-82-101-500	1	piece
2CKA006800A2832	Electronic Controls aluminium silver - Platform 63	6815-83-101-500	1	piece
2CKA006800A2834	Electronic Controls studio white - Platform 63	6815-84-101-500	1	piece
2CKA006800A2843	Electronic Controls stainless steel - Pure Stainless Steel	6815-866-101-500	1	piece
2CKA008200A0115	Cover plate Loudspeaker grey metallic - Platform 63	8253-803	1	piece
2CKA008200A0078	Cover plate Loudspeaker anthracite - Platform 63	8253-81	1	piece
2CKA008200A0079	Cover plate Loudspeaker ivory white - Platform 63	8253-82	1	piece
2CKA008200A0080	Cover plate Loudspeaker aluminium silver - Platform 63	8253-83	1	piece
2CKA008200A0081	Cover plate Loudspeaker studio white - Platform 63	8253-84	1	piece
2CKA008200A0087	Cover plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	piece
2CKA008200A0123	Cover plate Loudspeaker studio white matt - Platform 63	8253-884	1	piece
2CKA008300A0226	Welcome, anthracite	83260-81-515	1	piece
2CKA008300A0225	Welcome, studio white	83260-84-515	1	piece
2CKA006220A0566	CP-FCC-803 C-plate Fan Coil	CP-FCC-803	1	piece
2CKA006220A0242	CP-FCC-81 C-plate Fan Coil	CP-FCC-81	1	piece
2CKA006220A0532	CP-FCC-82 C-plate Fan Coil	CP-FCC-82	1	piece
2CKA006220A0243	CP-FCC-83 C-plate Fan Coil	CP-FCC-83	1	piece
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	piece
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	piece
2CKA006220A0617	CP-FCC-884 C-plate Fan Coil	CP-FCC-884	1	piece
2CKA006220A0563	CP-RTC-803 C-plate RT sensor unit	CP-RTC-803	1	piece
2CKA006220A0179	CP-RTC-81 C-plate RT sensor unit	CP-RTC-81	1	piece
2CKA006220A0529	CP-RTC-82 C-plate RT sensor unit	CP-RTC-82	1	piece
2CKA006220A0180	CP-RTC-83 C-plate RT sensor unit	CP-RTC-83	1	piece
2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	piece
2CKA006220A0384	CP-RTC-840 c-plate temp.	CP-RTC-840	1	piece
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	piece
2CKA006220A0614	CP-RTC-884 C-plate RT sensor unit	CP-RTC-884	1	piece
2CKA006220A0564	MD-F-1.0.1-803 Movement detector	MD-F-1.0.1-803	1	piece
2CKA006220A0212	MD-F-1.0.1-81 Movement detector	MD-F-1.0.1-81	1	piece
2CKA006220A0530	MD-F-1.0.1-82 Movement detector	MD-F-1.0.1-82	1	piece
2CKA006220A0213	MD-F-1.0.1-83 Movement detector	MD-F-1.0.1-83	1	piece
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	piece
2CKA006220A0385	MD-F-1.0.1-840 WD 180 sens	MD-F-1.0.1-840	1	piece
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	piece
2CKA006220A0615	MD-F-1.0.1-884 Movement detector	MD-F-1.0.1-884	1	piece

2CKA006220A0565	MSA-F-1.1.1-803 Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	piece
2CKA006220A0215	MSA-F-1.1.1-81 Mov. detector/actuator 1g	MSA-F-1.1.1-81	1	piece
2CKA006200A0083	MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	piece
2CKA006200A0084	MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	piece
2CKA006220A0216	MSA-F-1.1.1-83 Mov. detector/actuator 1g	MSA-F-1.1.1-83	1	piece
2CKA006200A0085	MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	piece
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	piece
2CKA006220A0386	MSA-F-1.1.1-840 WD 180 sens actuator	MSA-F-1.1.1-840	1	piece
2CKA006200A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	piece
2CKA006220A0616	MSA-F-1.1.1-884 Mov. detector/actuator 1g	MSA-F-1.1.1-884	1	piece
2CKA006200A0097	MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	piece
2CKA006220A0550	Electronic Controls grey metallic - Platform 63	SR-1-803	1	piece
2CKA006220A0137	Rocker anthracite - Platform 63	SR-1-81	1	piece
2CKA006220A0516	Rocker ivory white - Platform 63	SR-1-82	1	piece
2CKA006220A0138	Rocker aluminium silver - Platform 63	SR-1-83	1	piece
2CKA006220A0139	Rocker studio white - Platform 63	SR-1-84	1	piece
2CKA006220A0371	Rocker antique brass - Platform 63	SR-1-840	1	piece
2CKA006220A0533	Rocker stainless steel - Pure Stainless Steel	SR-1-866	1	piece
2CKA006220A0601	Rocker studio white matt - Platform 63	SR-1-884	1	piece
2CKA006220A0555	Electronic Controls grey metallic - Platform 63	SR-2-803	1	piece
2CKA006220A0152	Rocker anthracite - Platform 63	SR-2-81	1	piece
2CKA006220A0521	Rocker ivory white - Platform 63	SR-2-82	1	piece
2CKA006220A0153	Rocker aluminium silver - Platform 63	SR-2-83	1	piece
2CKA006220A0154	Rocker studio white - Platform 63	SR-2-84	1	piece
2CKA006220A0376	Rocker antique brass - Platform 63	SR-2-840	1	piece
2CKA006220A0538	Rocker stainless steel - Pure Stainless Steel	SR-2-866	1	piece
2CKA006220A0606	Rocker studio white matt - Platform 63	SR-2-884	1	piece
2CKA006220A0552	Electronic Controls grey metallic - Platform 63	SRB-1-803	1	piece
2CKA006220A0143	Rocker anthracite - Platform 63	SRB-1-81	1	piece
2CKA006220A0518	Rocker ivory white - Platform 63	SRB-1-82	1	piece
2CKA006220A0144	Rocker aluminium silver - Platform 63	SRB-1-83	1	piece
2CKA006220A0145	Rocker studio white - Platform 63	SRB-1-84	1	piece
2CKA006220A0373	Rocker antique brass - Platform 63	SRB-1-840	1	piece
2CKA006220A0535	Rocker stainless steel - Pure Stainless Steel	SRB-1-866	1	piece
2CKA006220A0603	Rocker studio white matt - Platform 63	SRB-1-884	1	piece
2CKA006220A0557	Electronic Controls grey metallic - Platform 63	SRB-2-803	1	piece
2CKA006220A0158	Rocker Symbol "arrows" anthracite - Platform 63	SRB-2-81	1	piece
2CKA006220A0523	Rocker Symbol "arrows" ivory white - Platform 63	SRB-2-82	1	piece
2CKA006220A0159	Rocker Symbol "arrows" aluminium silver - Platform 63	SRB-2-83	1	piece
2CKA006220A0160	Rocker Symbol "arrows" studio white - Platform 63	SRB-2-84	1	piece
2CKA006220A0378	Rocker Symbol "arrows" antique brass - Platform 63	SRB-2-840	1	piece
2CKA006220A0540	Rocker Symbol "arrows" stainless steel - Pure Stainless Steel	SRB-2-866	1	piece
2CKA006220A0608	Rocker Symbol "arrows" studio white matt - Platform 63	SRB-2-884	1	piece
2CKA006220A0554	Electronic Controls grey metallic - Platform 63	SRD-1-803	1	piece
2CKA006220A0149	Rocker Symbol "dimming" anthracite - Platform 63	SRD-1-81	1	piece

2CKA006220A0520	Rocker Symbol "dimming" ivory white - Platform 63	SRD-1-82	1	piece
2CKA006220A0150	Rocker Symbol "dimming" aluminium silver - Platform 63	SRD-1-83	1	piece
2CKA006220A0151	Rocker Symbol "dimming" studio white - Platform 63	SRD-1-84	1	piece
2CKA006220A0375	Rocker Symbol "dimming" antique brass - Platform 63	SRD-1-840	1	piece
2CKA006220A0537	Rocker Symbol "dimming" stainless steel - Pure Stainless Steel	SRD-1-866	1	piece
2CKA006220A0605	Rocker Symbol "dimming" studio white matt - Platform 63	SRD-1-884	1	piece
2CKA006220A0559	Electronic Controls grey metallic - Platform 63	SRD-2-L-803	1	piece
2CKA006220A0164	Rocker Symbol "dimming" anthracite - Platform 63	SRD-2-L-81	1	piece
2CKA006220A0525	Rocker Symbol "dimming" ivory white - Platform 63	SRD-2-L-82	1	piece
2CKA006220A0165	Rocker Symbol "dimming" aluminium silver - Platform 63	SRD-2-L-83	1	piece
2CKA006220A0166	Rocker Symbol "dimming" studio white - Platform 63	SRD-2-L-84	1	piece
2CKA006220A0380	Rocker Symbol "dimming" antique brass - Platform 63	SRD-2-L-840	1	piece
2CKA006220A0542	Rocker Symbol "dimming" stainless steel - Pure Stainless Steel	SRD-2-L-866	1	piece
2CKA006220A0610	Rocker Symbol "dimming" studio white matt - Platform 63	SRD-2-L-884	1	piece
2CKA006220A0560	Electronic Controls grey metallic - Platform 63	SRD-2-R-803	1	piece
2CKA006220A0258	Rocker Symbol "dimming" anthracite - Platform 63	SRD-2-R-81	1	piece
2CKA006220A0526	Rocker Symbol "dimming" ivory white - Platform 63	SRD-2-R-82	1	piece
2CKA006220A0259	Rocker Symbol "dimming" aluminium silver - Platform 63	SRD-2-R-83	1	piece
2CKA006220A0260	Rocker Symbol "dimming" studio white - Platform 63	SRD-2-R-84	1	piece
2CKA006220A0383	Rocker Symbol "dimming" antique brass - Platform 63	SRD-2-R-840	1	piece
2CKA006220A0543	Rocker Symbol "dimming" stainless steel - Pure Stainless Steel	SRD-2-R-866	1	piece
2CKA006220A0611	Rocker Symbol "dimming" studio white matt - Platform 63	SRD-2-R-884	1	piece
2CKA006220A0551	Electronic Controls grey metallic - Platform 63	SRL-1-803	1	piece
2CKA006220A0140	Rocker Symbol "light" anthracite - Platform 63	SRL-1-81	1	piece
2CKA006220A0517	Rocker Symbol "light" ivory white - Platform 63	SRL-1-82	1	piece
2CKA006220A0141	Rocker Symbol "light" aluminium silver - Platform 63	SRL-1-83	1	piece
2CKA006220A0142	Rocker Symbol "light" studio white - Platform 63	SRL-1-84	1	piece
2CKA006220A0372	Rocker Symbol "light" antique brass - Platform 63	SRL-1-840	1	piece
2CKA006220A0534	Rocker Symbol "light" stainless steel - Pure Stainless Steel	SRL-1-866	1	piece
2CKA006220A0602	Rocker Symbol "light" studio white matt - Platform 63	SRL-1-884	1	piece
2CKA006220A0556	Electronic Controls grey metallic - Platform 63	SRL-2-L-803	1	piece
2CKA006220A0155	Rocker Symbol "light" anthracite - Platform 63	SRL-2-L-81	1	piece
2CKA006220A0522	Rocker Symbol "light" ivory white - Platform 63	SRL-2-L-82	1	piece
2CKA006220A0156	Rocker Symbol "light" aluminium silver - Platform 63	SRL-2-L-83	1	piece
2CKA006220A0157	Rocker Symbol "light" studio white - Platform 63	SRL-2-L-84	1	piece
2CKA006220A0377	Rocker Symbol "light" antique brass - Platform 63	SRL-2-L-840	1	piece
2CKA006220A0539	Rocker Symbol "light" stainless steel - Pure Stainless Steel	SRL-2-L-866	1	piece
2CKA006220A0607	Rocker Symbol "light" studio white matt - Platform 63	SRL-2-L-884	1	piece
2CKA006220A0561	Electronic Controls grey metallic - Platform 63	SRL-2-R-803	1	piece
2CKA006220A0167	Rocker Symbol "light" anthracite - Platform 63	SRL-2-R-81	1	piece
2CKA006220A0527	Rocker Symbol "light" ivory white - Platform 63	SRL-2-R-82	1	piece

2CKA006220A0168	Rocker Symbol "light" aluminium silver - Platform 63	SRL-2-R-83	1	piece
2CKA006220A0169	Rocker Symbol "light" studio white - Platform 63	SRL-2-R-84	1	piece
2CKA006220A0381	Rocker Symbol "light" antique brass - Platform 63	SRL-2-R-840	1	piece
2CKA006220A0544	Rocker Symbol "light" stainless steel - Pure Stainless Steel	SRL-2-R-866	1	piece
2CKA006220A0612	Rocker Symbol "light" studio white matt - Platform 63	SRL-2-R-884	1	piece
2CKA006220A0553	Electronic Controls grey metallic - Platform 63	SRS-1-803	1	piece
2CKA006220A0146	Rocker Symbol "scene" anthracite - Platform 63	SRS-1-81	1	piece
2CKA006220A0519	Rocker Symbol "scene" ivory white - Platform 63	SRS-1-82	1	piece
2CKA006220A0147	Rocker Symbol "scene" aluminium silver - Platform 63	SRS-1-83	1	piece
2CKA006220A0148	Rocker Symbol "scene" studio white - Platform 63	SRS-1-84	1	piece
2CKA006220A0374	Rocker Symbol "scene" antique brass - Platform 63	SRS-1-840	1	piece
2CKA006220A0536	Rocker Symbol "scene" stainless steel - Pure Stainless Steel	SRS-1-866	1	piece
2CKA006220A0604	Rocker Symbol "scene" studio white matt - Platform 63	SRS-1-884	1	piece
2CKA006220A0558	Electronic Controls grey metallic - Platform 63	SRS-2-L-803	1	piece
2CKA006220A0161	Rocker Symbol "scene" anthracite - Platform 63	SRS-2-L-81	1	piece
2CKA006220A0524	Rocker Symbol "scene" ivory white - Platform 63	SRS-2-L-82	1	piece
2CKA006220A0162	Rocker Symbol "scene" aluminium silver - Platform 63	SRS-2-L-83	1	piece
2CKA006220A0163	Rocker Symbol "scene" studio white - Platform 63	SRS-2-L-84	1	piece
2CKA006220A0379	Rocker Symbol "scene" antique brass - Platform 63	SRS-2-L-840	1	piece
2CKA006220A0541	Rocker Symbol "scene" stainless steel - Pure Stainless Steel	SRS-2-L-866	1	piece
2CKA006220A0609	Rocker Symbol "scene" studio white matt - Platform 63	SRS-2-L-884	1	piece
2CKA006220A0562	Electronic Controls grey metallic - Platform 63	SRS-2-R-803	1	piece
2CKA006220A0173	Rocker Symbol "scene" anthracite - Platform 63	SRS-2-R-81	1	piece
2CKA006220A0528	Rocker Symbol "scene" ivory white - Platform 63	SRS-2-R-82	1	piece
2CKA006220A0174	Rocker Symbol "scene" aluminium silver - Platform 63	SRS-2-R-83	1	piece
2CKA006220A0175	Rocker Symbol "scene" studio white - Platform 63	SRS-2-R-84	1	piece
2CKA006220A0382	Rocker Symbol "scene" antique brass - Platform 63	SRS-2-R-840	1	piece
2CKA006220A0545	Rocker Symbol "scene" stainless steel - Pure Stainless Steel	SRS-2-R-866	1	piece
2CKA006220A0613	Rocker Symbol "scene" studio white matt - Platform 63	SRS-2-R-884	1	piece

Categories

Low Voltage Products and Systems → Building and Home Automation Solutions → free@home → User Operation
 Low Voltage Products and Systems → Building and Home Automation Solutions → KNX → User Operation
 Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Frames



360°